

EasyNO_x – NO_x Monitoring

Operating Manual



P/N 01.50.026-EN | Rev. 12/2020

Original instructions

© Copyright 2020 MOTORTECH GmbH. All rights reserved.

MOTORTECH products and the MOTORTECH logo are registered and/or common law trademarks of the MOTORTECH GmbH. All further trademarks and logos displayed or used in this publication are the property of the respective entitled person and are used for reference purposes only.

Information contained in this publication may be changed without prior notice.

1 General Information	6
1.1 What Is the Purpose of this Operating Manual?	6
1.2 Who Is this Operating Manual Targeted to?	6
1.3 Which Symbols Are Used in the Operating Manual?	6
1.4 Which Abbreviations/Acronyms Are Used in the Operating Manual?	7
2 Safety Instructions	9
2.1 General Safety Instructions	9
2.2 Electrostatic Discharge Hazards	10
2.3 Information on Electric Isolation	11
2.4 Special Safety Instructions	13
2.4.1 EasyNO _x System	13
2.4.2 NO _x Sensor	16
2.5 Proper Transport	16
2.6 Proper Disposal	17
3 Intended Use	18
3.1 Functional Description	18
3.1.1 NO _x Monitor	18
3.2 Applications	19
4 Product Description	21
4.1 Technical Data	21
4.1.1 Certifications	21
4.1.2 Mechanical Data	22
4.1.3 Product Identification – Labeling on the Device	25
4.1.4 Electrical Data	27
4.1.5 Display	30
4.1.6 Interfaces	30
4.1.7 Overview Drawings	31
4.1.7.1 Dimensions	31
4.1.7.2 Components	35
4.1.8 Ports/Connections and LEDs	37
5 Installation Instruction	40
5.1 Unpacking	40
5.2 Mounting of EasyNO _x	41
5.3 Mounting of CAN Bus/NO _x Sensor Module	41
5.4 Mounting the Sensing Element of the NO _x Sensor	42
5.5 Determining NO ₂ /NO _x Ratio	45

■ Table of Contents

5.6 Mounting of I/O Communication Module.....	46
5.7 Installation Locations of Thermocouples	46
5.8 Installation Location of Manifold Pressure Sensor	48
5.9 Determining Charging Pressure for Normal Operation Detection	48
6 Wiring and Configuration	49
6.1 EasyNO _x	49
6.2 CAN Bus/NO _x Sensor Module	52
6.3 CAN Bus Wiring CAN1.....	57
6.4 I/O Communication Module	59
7 General Operation.....	62
7.1 Switching on and off the Device	62
7.2 Navigation	62
7.3 Menu Bar	64
7.4 Start Menu	66
7.4.1 Devices	69
7.4.1.1 Device Activation	71
7.4.1.2 Adding a Device	72
7.4.1.3 Editing a Device	75
7.4.1.4 Deleting a Device	75
7.4.2 Display	76
7.4.3 Connection.....	79
7.5 Access Control.....	80
7.5.1 Enabling/Disabling Access Control.....	82
7.5.2 Logging in and Logging out	83
7.5.3 Changing the PIN	84
7.5.4 Resetting the PINs	84
7.6 Event Log	86
7.7 Help.....	87
8 Devices.....	88
8.1 NO _x Monitor	88
8.1.1 Main Menu	89
8.1.2 Overview	90
8.1.3 History.....	95
8.1.4 Logbook.....	97
8.1.5 Export	99
8.1.6 Preferences.....	101
8.2 I/O Communication Module	105

8.2.1	Main Menu	105
8.2.2	Preferences.....	106
8.2.2.1	Binary Inputs	107
8.2.2.2	Binary Outputs	108
8.2.2.3	Analog Inputs.....	109
8.2.2.4	Analog Outputs	110
8.3	Generic Device	111
9	Errors	112
9.1	Possible Faults	112
9.2	Customer Service Information	113
9.3	Returning Equipment for Repair / Inspection	114
9.4	Instructions for Packaging the Equipment	114
10	Maintenance	115
10.1	Cleaning the Touchscreen	115
10.2	Maintenance of Housing.....	115
10.3	Battery Change	115
10.4	Replacing the NO_x Sensor.....	116
10.5	Software Update	118

1 General Information

Read through this operating manual carefully before use and become familiar with the product. Installation and start-up should not be carried out before reading and understanding this document. Keep this manual readily available so that you can reference it as needed.

1.1 What Is the Purpose of this Operating Manual?

This manual serves as an aid for the installation and operation of the product and supports the technical staff with all operating and maintenance tasks to be performed. Furthermore, this manual is aimed at preventing dangers to life and health of the user and third parties.

1.2 Who Is this Operating Manual Targeted to?

The operating manual provides a code of conduct for personnel tasked with the setup, operation, maintenance, and repair of gas engines. A certain level of technical knowledge with respect to the operation of gas engines and basic knowledge of electronic ignition systems are necessary. Persons who are only authorized to operate the gas engine shall be trained by the operating company and shall be expressly instructed concerning potential hazards.

1.3 Which Symbols Are Used in the Operating Manual?

The following symbols are used in this manual and must be observed:



Example

This symbol indicates examples, which point out necessary handling steps and techniques. In addition, you receive additional information from the examples, which will increase your knowledge.



Notice

This symbol indicates important notices for the user. Follow these. In addition, this symbol is used for overviews that give you a summary of the necessary work steps.



Warning

This symbol indicates warnings for possible risks of property damage or risks to health. Read these warning notices carefully and take the mentioned precautionary measures.



Danger

This symbol indicates warnings for danger to life, especially due to high voltage. Read these warning notices carefully and take the mentioned precautionary measures.

1.4 Which Abbreviations/Acronyms Are Used in the Operating Manual?

In the operating manual or the user interface, the following abbreviations/acronyms are used.

Abb.	Term	Description	Explanation
CAN bus	Controller Area Network bus	Bus for control devices / networks	Asynchronous serial connection system for linking control units
CE	Conformité Européenne	Conformity with EU directives	Mark based on EU legislation for certain products in conjunction with product safety
CSV	Comma-separated Values	Data separated by comma	Text file for storage or exchange of structured data
DC	Direct Current		
DIP	Dual In-Line Package		Housing form for electronic components with two rows of connections for push-fit assembly
DIS	Draft International Standard		Draft ISO standard
EMC	Electromagnetic Compatibility		Compatibility of electrical or electronic equipment items with their surroundings
ESD	Electrostatic Discharge		
HMI	Human-Machine Interface		Interface between human and machine or computer
I/O	Input/Output		Communication of an information system with the outside world
ISO	International Organization for Standardization		

1 General Information

Abb.	Term	Description	Explanation
LED	Light Emitting Diode		Light emitting electronic semi-conductor
MAP	Manifold Absolute Pressure		
MMC	Multimedia Card		Digital storage medium
PRAK	PIN Reset Authorization Key	Key for resetting all PINs	Key that resets all PINs of the EasyNO _x .
PRRK	PIN Reset Request Key	Key for applying for a PIN reset key	Key with which the key for resetting all EasyNO _x PINs can be requested.
QR	Quick Response		
RoHS	Restriction of Hazardous Substances		
SD card	Secure Digital card	Secure digital data storage medium	Digital storage medium
SDHC card	Secure Digital High-Capacity card	Secure, high-capacity digital memory card	Digital storage medium
USB	Universal Serial Bus		Serial connection system to link a computer to external devices
UTC	Coordinated Universal Time		
XML	Extensible Markup Language		Markup language for displaying hierarchically structured data

2.1 General Safety Instructions

The following safety instructions must be followed in the area in which the device is operated:



High voltage! Danger to life!

While the engine is running, there is danger to life through high voltage particularly in the area of the ignition system. The following parts should therefore not be touched or removed unless explicitly stated otherwise:

- Ignition coils and caps
- Wires of the high voltage circuit
- In- and output wiring of the ignition controller
- Pickups and their wiring



Danger to persons with pacemakers!

Electromagnetic impulses in the wiring of the ignition system may exceed the permissible limits of pacemakers. Persons with pacemakers must therefore not be present in the vicinity of the ignition system being operated. Mark the operating location of the ignition system with the corresponding standardized warning symbol.

MOTORTECH equipment is manufactured as state of the art and therefore safe and reliable to operate. Nevertheless the equipment can cause risks or damage can occur, if the following instructions are not complied with:

- The gas engine must only be operated by trained and authorized personnel.
- Observe all safety instructions of the system and all safety instructions of the system operator.
- Operate the equipment only within the parameters specified in the technical data.
- Use the equipment correctly and for its intended use only.
- Never apply force.
- For all work such as installation, conversion, adaptation, maintenance, and repair, all equipment must be disconnected from the mains and secured against unintentional reactivation.
- Perform only such maintenance and repair work as is described in this operating manual, and follow the instructions given while working.
- Only use spare parts supplied by MOTORTECH for the maintenance of the device.
- Further work must only be performed by personnel authorized by MOTORTECH. Non-compliance with the instructions will void any warranties for the proper function of the equipment as well as the responsibility for the validity of the certifications.
- Safety devices must not be dismantled or disabled.

■ 2 Safety Instructions

- Avoid all activities that can impair the function of the equipment.
- Operate the equipment only while it is in proper condition.
- Investigate all changes detected while operating the gas engine or ignition system.
- Ensure compliance with all laws, directives, and regulations applicable to the operation of your system, including such not expressly stated herein.
- If the system is not entirely tight and sealed, gas may escape and result in explosion hazard. The inhalation of gas can also lead to death or severe health damages. Therefore, upon completion of all assembly works, always check the system's tightness.
- Always ensure adequate ventilation of the engine compartment.
- Ensure a safe position at the gas engine.
- There is a risk of burning on hot surfaces. Allow the gas engine to cool down before starting any work.
- Personal protective equipment (PPE), e.g. safety shoes and gloves, must be worn during all work on the gas engine.
- Noise from the system can cause permanent or temporary damage to your hearing. Wear suitable hearing protection at the system.
- Your behavior can reduce possible residual risks to a minimum. Observe responsible handling of the gas engine and the gas-carrying system.

2.2 Electrostatic Discharge Hazards

Electronic equipment is sensitive to static electricity. To protect these components from damage caused by static electricity, special precautions must be taken to minimize or prevent electrostatic discharge.

Observe these safety precautions while you work with the equipment or in its vicinity.

- Before performing maintenance or repair work, ensure that the static electricity inherent to your body is discharged.
- Do not wear clothing made from synthetic materials to prevent static electricity from building up. Your clothing should therefore be made of cotton or cotton mix materials.
- Keep plastics such as vinyl and Styrofoam materials as far away from the equipment as possible.
- Do not remove the circuit boards from the housing of the device.


2.3 Information on Electric Isolation

If ground and earth potential are not properly isolated, the following problems as well as others can occur:

- Electromagnetic interferences (e.g. ground loops)
- Signal corruption (e.g. of the analog voltage signal)
- Unwanted leakage currents

Therefore, earth potential and the negative pole of the power supply of all devices in the electric assembly that provide the option, should be connected separately. If possible, the negative pole of the power supply should only be connected to earth potential at one point in the entire system.

Wiring Example




2 Safety Instructions



Occurrence of ground loops

The devices shown in the following image do not feature the possibility to connect the earth potential and the negative pole of the power supply separated from each other. How ground loops are created.

A ground loop is a ground connection of an electric wiring assembly that is closed as a loop. Due to impedance (resistance $R > 0$) of the loop, low-frequency interference currents can lead to an unwanted voltage drop in the signal path.



2.4 Special Safety Instructions

2.4.1 EasyNO_x System



Explosion hazard!

In the event of a malfunction, ignitable sparks may be generated in the EasyNO_x system. Therefore, take appropriate measures to ensure that no explosive gases are formed in the system area.



Risk of suffocation! Risk of poisoning!

Leaks in the exhaust pipe can cause exhaust gases to escape and people in the system room can suffocate or be poisoned. After mounting the sensors, check the tightness of the exhaust pipe.



Risk of burning!

There is a risk of burns when touching the sensing elements of the NO_x sensor and the thermocouples because the sensing elements become hot during operation. Therefore, note the following points:

- Therefore, install the sensing elements on the exhaust pipe at a suitable location at which people at the plant cannot be burned by them, or install an appropriate protection around the sensing elements that prevents contact with them.
- The sensing elements must have cooled down sufficiently at the end of operation before you can touch the sensing elements again.



Risk of destruction and injury!

The EasyNO_x is an electrically operated device and there is the risk of electrostatic discharges. Therefore, never operate the device without the appropriate grounding, to prevent injuries and damage.

2 Safety Instructions



Risk of injury!

The EasyNO_x is designed for operation in circuits with **protected extra-low voltage (PELV)**. The voltages in these circuits must not exceed 50 V AC or 75 V DC.

The EasyNO_x must not be electrically connected to circuits which carry dangerously high voltages or which could lead to a single failure.

Therefore, the following conditions, among others, must be fulfilled:

- The power supply may only be provided from power supply units with safe electrical isolation or from batteries.
- Relays with safe isolation must be used for coupling to circuits that carry dangerous voltages or could carry in the event of a failure.
- All currently applicable standards and regulations must be taken into account.



Operational safety!

The devices of the EasyNO_x system must be operated with closed housings. Otherwise, proper functioning of the devices and compliance with the protection classes cannot be guaranteed.

When the system is powered off, the housings may be opened for wiring and configuration if necessary. When the housing is open, make sure that no moisture forms in the housing.



Operational safety!

To prevent arcing or sparking and short circuits that can cause electric shock and serious damage to the connected equipment, always switch off the power supply to the EasyNO_x system before disconnecting the electrical connections in the EasyNO_x system.



Operational safety!

The EasyNO_x and the software are not designed for safety-critical applications. The binary inputs and outputs of the EasyNO_x system must not be used for safety-critical purposes.



Risk of destruction!

When using the EasyNO_x, observe the following points:

- Do not let the device fall.
- The device must not come into contact with water and other liquids.
- Do not operate the device in direct sunlight, near heat sources or in humid environments.
- Only operate the device according to the technical specifications.

Disregard of these guidelines can lead to the destruction of the device.



Risk of damage and malfunctions!

Safe operation is no longer guaranteed in the following cases:

- The EasyNO_x shows visible damage.
- The display remains dark or shows unusual patterns for a longer period of time.
- The screen saver does not turn off when touching the display.
- The EasyNO_x does not react after a restart.

The EasyNO_x must then be turned off and must not be used any longer.



Risk of destruction!

The surface of the touchscreen is sensitive to pointed and sharp-edged objects. Therefore handle the touchscreen carefully. Pixel errors due to improper handling are excluded from the warranty.



Danger of interference with radio reception!

The EasyNO_x system is not intended for use in residential areas and cannot ensure adequate protection of radio reception in such environments.

2 Safety Instructions

2.4.2 NO_x Sensor



Explosion hazard!

Only use the NO_x sensor for measurement in non-explosive gas mixtures, as explosive gas mixtures can ignite on the hot sensing element. Especially in the case of engine malfunction, make sure that no unburned gas mixture enters the exhaust pipe.



Operational safety!

The chemical elements magnesium (Mg), silicon (Si), phosphorus (P), and sulfur (S) can change the measuring characteristics of the NO_x sensor. Make sure that these chemical elements are not present in your application. Do not use sprays containing these chemical elements. Only use material in the exhaust pipe free of these chemical elements.



Operational safety!

To ensure proper functioning of the NO_x sensor, the probe must not come into contact with condensation water and other liquid components. The sensor and its electronics must not be painted either. Do not open the cover of the evaluation unit's connector.



Operational safety!

The sensing element may be mounted and dismantled a maximum of two times. The electrical connection to the NO_x sensor's evaluation unit may be established and disconnected a maximum of 20 times. After that, proper functioning of the sensor can no longer be guaranteed.

2.5 Proper Transport

Let the EasyNO_x system and in particular the sensing element of the NO_x sensor remain in their original packaging until they reach their place of use.

After unpacking, secure the EasyNO_x housing against falling over, dropping and slipping.

After unpacking, take care not to twist the wires (max. 180°) in the connecting cable between the sensing element and the evaluation unit of the NO_x sensor when carrying the CAN bus/NO_x sensor module. Under no circumstances should you wrap the connection cable around the evaluation unit, but wrap the connection cable separately from the module and maintain the minimum bending radius of 20 mm (0.79"). Do not remove the protective cap from the NO_x sensor's sensing element until you are instructed to do so within this operating manual (see section *Mounting the Sensing Element of the NO_x Sensor* on page 42).

2.6 Proper Disposal

After the expiration of its service life, MOTORTECH equipment can be disposed of with other commercial waste, or it may be returned to MOTORTECH. We will ensure its environmentally friendly disposal.

3 Intended Use

3.1 Functional Description

The EasyNO_x is used to visualize and record engine operating data. The data can be provided by the following devices:

- EasyNO_x CAN bus/NO_x sensor module
- I/O communication module

The NO_x monitor and the I/O communication module are fully configurable via the EasyNO_x. A USB port allows recorded data to be saved to a USB flash drive. Simultaneously, the EasyNO_x can integrate up to two NO_x monitors and two I/O communication modules.

The optionally available I/O communication module provides the EasyNO_x with analog and binary inputs and outputs for communication with a master control and for signalling warnings and errors.

3.1.1 NO_x Monitor

The NO_x monitor of the EasyNO_x monitors the exhaust gases of stationary industrial gas engines. Up to two thermocouples per engine are additionally used to measure the exhaust gas temperature near the catalytic converter. Via the EasyNO_x the measured data can be displayed and stored and the operating parameters can be configured.

For up to two engines, the NO_x monitor displays the current nitrogen oxide and oxygen concentration measured value of each connected NO_x sensor, the nitrogen oxide measured value converted to standard volume with a reference oxygen content of 5 % according to VDMA 6299:2019-09 and the provisional daily average of the nitrogen oxide measured values. With the EXTENDED package of the EasyNO_x, the nitrogen oxide measured value converted according to VDMA 6299:2019-09 can also be output to a master control via an analog output.

For the nitrogen oxide daily average you define a level limit that must not be exceeded and a warning level that indicates that the daily average is approaching the level limit. If the final nitrogen oxide daily average exceeds the specified level limit, the detected normal operation hours of the respective day are added to a failure hour counter for the current calendar year. For this failure hour counter, you specify a time limit in the EasyNO_x that must not be exceeded and a warning threshold that indicates that the failure hour counter is approaching the time limit.

The exhaust gas temperature monitoring of the NO_x monitor serves to monitor catalyst operation as well as to detect the dew point for the NO_x sensor and is designed for thermocouples of type K. For up to two measuring points, you define a temperature threshold each, which must not be exceeded. If the exhaust gas temperature is to be monitored both before and after the catalytic converter, you can also define the permissible temperature difference range of the exhaust gas between the catalyst inlet and outlet.

The NO_x monitor of the EasyNO_x calculates the nitrogen oxide daily average from valid measured values of the NO_x sensor in normal operation, provided that the dew point of the NO_x sensor has been reached for at least 5 minutes at the catalyst outlet.

For detecting normal operation, the NO_x monitor can evaluate the load signal of a master control connected to the CAN bus module of the EasyNO_x system. With the EXTENDED package, this load signal can also be connected to the I/O communication module. Alternatively, the NO_x monitor can use the absolute charging pressure as an indicator for the engine load. For this purpose, a manifold pressure sensor can be connected directly to the CAN bus module of the EasyNO_x system or alternatively the signal of a manifold pressure sensor can be forwarded to the CAN bus module via the control cabinet. With the EXTENDED package, there is also the option that a master control indicates normal operation via the binary input of the I/O communication module.

The NO_x monitor of the EasyNO_x logs each measurement sample in a daily log and summarizes the measurement results of the day in an annual log. In a logbook, the EasyNO_x logs emissions-related events of the NO_x monitor. User-defined entries can also be made in this logbook. Via the USB interface of the EasyNO_x the logs and the logbook can be exported to a USB flash drive.

3.2 Applications



Danger of interference with radio reception!

The EasyNO_x system is not intended for use in residential areas and cannot ensure adequate protection of radio reception in such environments.

The EasyNO_x system designed for use on stationary gas engines in industrial environments in a non-hazardous area.

The EasyNO_x must only be operated with the devices specified for this purpose. The EasyNO_x does not support safety-critical applications.

The NO_x sensor of CAN bus/NO_x sensor module is suited for exhaust gases and exhaust pipes that are free of ammonia, magnesium, silicon, phosphorus, and sulfur and may only be used for measurements in non-explosive gas mixtures.


In exhaust gas lines equipped with an oxidizing or three-way catalytic converter, the NO_x monitor of the EasyNO_x can be used for qualitative monitoring and documentation of nitrogen oxide emissions in accordance with the 44. Ordinance Implementing the Federal Immission Control Act (BImSchV) and the standard sheet VDMA 6299:2019-09.

The NO_x monitor of the EasyNO_x can be used with two CAN bus/NO_x sensor modules to monitor two engines that are located in the same room in close proximity.

Any use other than the one described in the operating manual shall be considered improper use and will result in the voiding of all warranties.

3 Intended Use

System Overview (Example)



- 1 EasyNO_x
- 2 CAN bus/NO_x sensor module
- 3 I/O communication module
- 4 NO_x sensor
- 5 Thermocouple
- 6 Manifold pressure sensor

- A Control cabinet
- B Master control
- C Exhaust gas line
- D Catalytic converter
- E Engine

■ 4 Product Description



4.1 Technical Data

4.1.1 Certifications

The EasyNO_x is certified as follows:

CE

EMC Directive

- EN 61326-1 – Electrical equipment for measurement, control and laboratory use - EMC requirements - Part 1: General requirements
- EN 55011 – Industrial, scientific and medical equipment. Radio-frequency disturbance characteristics. Limits and methods of measurement
 - Group 1, Class A

RoHS Directive

Other standard applied:

- EN 61010-1 – Safety requirements for electrical equipment for measurement, control and laboratory- Part 1: General requirements

You can obtain the EU Declaration of Conformity for your EasyNO_x from your MOTORTECH contact person if required (see section *Customer Service Information* on page 113).

4 Product Description

4.1.2 Mechanical Data



Compliance with protection class

The specified protection classes are only guaranteed if all external cables are wired according to their specifications, all cable glands and screw openings are tightly closed and all covers are closed or mounted as specified.

The EasyNO_x has the following mechanical characteristics.

Feature	Value
Dimensions	305.6 mm x 230 mm x 86 mm (12.04" x 9.06" x 3.39") (length x width x height)
Weight	3.5 kg (7.8 lbs)
Shape of device	See section <i>Dimensions</i> on page 31
Mechanical environmental conditions	Protection: IP 66
Climatic environmental conditions	Operation: 0 °C to +50 °C (+32 °F to +122 °F) Housing closed: 5 % to 90 % humidity without condensation Condensation must be prevented by suitable measures Housing open : 5 % to 50 % humidity without condensation at +40 °C (+104 °F) 5 % to 90 % humidity without condensation at +20 °C (+68 °F) Storage: -20 °C to +70 °C (-4 °F to +158 °F) 30 % to 70 % humidity without condensation Up to 3,000 m (9,842') above sea level

■ 4 Product Description



The CAN bus/NO_x sensor module has the following mechanical characteristics:

Feature	Value
Dimensions	Length x width mounting plate: 206.5 mm x 150 mm (8.13" x 5.91") Height mounting plate with CAN bus module: 82 mm (3.23")
Weight	1.62 kg (3.6 lbs)
Shape of device	See section <i>Dimensions</i> on page 31
Mechanical environmental conditions	Protection: IP 66 with mating plug connected to evaluation unit of NO _x -sensor and sensing element mounted in suitable welding boss from MOTORTECH
Climatic environmental conditions	Operation: -40 °C to +85 °C (-40 °F to +185 °F) 5 % to 90 % humidity without condensation with closed housing Storage: -40 °C to +65 °C (-40 °F to +149 °F) 30 % to 70 % humidity without condensation with closed housing Up to 2,000 m (6,561') above sea level

4 Product Description

The sensing element of the NO_x sensor has the following mechanical characteristics:

Feature	Value
Dimensions	Length of probe: 25.4 mm (1") Length of sensing element: 96.9 mm (3.82") Length of connection cable: 900 mm (35.4")
Shape of device	See section <i>Dimensions</i> on page 31
Mechanical environmental conditions	Protection: IP 6K9K with mating plug connected to evaluation unit and sensing element mounted in suitable welding boss from MOTORTECH
Climatic environmental conditions	Exhaust gas temperature range: –40 °C to +800 °C (–40 °F to +1,472 °F) Operating temperature hexagon nut: –40 °C to +620 °C (–40 °F to +1,148 °F) Operating temperature sensing element grommet and connection cable: –40 °C to +200 °C (–40 °F to +392 °F) Operating pressure range: 800 mbar abs to 1,600 mbar abs
Mounting cycles	Max. 2
Service life	6,000 h with average temperature of evaluation unit at +90 °C (+194 °F)

The I/O communication module of the EasyNO_x EXTENDED package has the following mechanical characteristics:

Feature	Value
Dimensions	Without wiring: 100 mm x 97 mm x 48 mm (3.94" x 3.82" x 1.89") (length x width x height)
Weight	Without harnesses: 320 g (0.71 lbs)
Shape of device	See section <i>Dimensions</i> on page 31
Mechanical environmental conditions	Protection: IP20
Climatic environmental conditions	–40 °C to +85 °C (–40 °F to +185 °F) Max. 85 % humidity without condensation Up to 2,000 m (6,561') above sea level


4 Product Description



4.1.3 Product Identification – Labeling on the Device

EasyNO_x

On the outside of the housing



The image shows a label on the outside of the EasyNO_x housing. It features the MOTORTECH logo at the top. Below the logo, there are two input fields: P/N with the value 63.05.010 and S/N with the value 05042245. Further down, it says 'HMI Module' followed by another input field: S/N with the value 03094058. At the bottom, it states 'Made by MOTORTECH GmbH, 29223 Celle, Germany, www.mortortech.de' and includes the CE mark.

Abb.	Meaning
P/N	Part number of the EasyNO _x
S/N	Serial number of the EasyNO _x and under <i>HMI Module</i> the serial number of the EasyNO _x HMI module installed in the housing

EasyNO_x HMI Module

Rear side



The image shows a label on the rear side of the EasyNO_x HMI Module. It features the MOTORTECH logo at the top. Below the logo, it says 'HMI Module'. To the right of the logo, there are three input fields: P/N with the value 06.05.150, A/N with the value PV4.00.0000-000-AA-A, and S/N with the value 03094058.

Abb.	Meaning
P/N	Part number of the EasyNO _x HMI module
A/N	Arrangement number of the EasyNO _x HMI module
S/N	Serial number of the EasyNO _x HMI module

4 Product Description

CAN Bus/NO_x Sensor Module




Abb.	Meaning
P/N	Part number of the CAN bus/NO _x sensor module
S/N	Serial number of the CAN bus/NO _x sensor module

CAN Bus Module

On the outside of the housing





Abb.	Meaning
P/N	Part number of the CAN bus module

NO_x Sensor

The part number (P/N) of the NO_x sensor can be found on the upper label on the bottom side of the evaluation unit.



The date of manufacture and the serial number of the NO_x sensor can be read out via the two-dimensional matrix code (Data Matrix) on the connector of the evaluation unit. For this purpose you can use a QR scanner, for example, which can also read Data Matrix codes. You will find the relevant information at the following positions in the read-out 49-character long string:

Position	Meaning
22 + 23	Year of manufacture (3rd and 4th digit)
24 + 25	Month of manufacture
26 + 27	Day of manufacture
28 – 31	Serial number

4 Product Description



I/O Communication Module (EXTENDED Package)

On the bottom side of the top hat rail spring clip



P/N 63.05.014-01
S/N 05042922

Abb.	Meaning
P/N	Part number of the I/O communication module

4.1.4 Electrical Data

The EasyNO_x has the following electrical characteristics:

Feature	Value
Power consumption	Without CAN bus/NO _x sensor module: 5.3 W typical, max. 22.8 W With up to two CAN bus/NO _x sensor modules: max. 67 W
Power supply	Nominal voltage: 24 V DC Operating voltage: 16 V DC to 32 V DC
Required current	Without CAN bus/NO _x sensor module: max. 1.5 A With up to two CAN bus/NO _x sensor modules: max. 4.2 A
Real-time clock accuracy	± 30 ppm at 25 °C (77 °F)
Internal backup battery	Type: CR1220 (3 V, Li-Ion) Service life: approx. 8 years (depending on application)

4 Product Description

The measuring inputs of the CAN bus module have the following electrical data:

Feature	Value
Resolution	16 bit
Thermocouple inputs	Quantity: 2 Suitable for thermocouples of type K, class 1 as per IEC 584 With cold junction compensation Measuring range: $-200\text{ }^{\circ}\text{C}$ to $+1,200\text{ }^{\circ}\text{C}$ ($-328\text{ }^{\circ}\text{F}$ to $+2,192\text{ }^{\circ}\text{F}$) Measurement resolution: 0.1 K Measuring accuracy: $\pm 0.1\text{ K}$ Sampling rate: 100 Hz per input The measuring point of the thermocouple must be insulated from the housing.
Analog current inputs	Quantity: 2 Permissible current: max. 22 mA Current range for measured values: 4 mA to 20 mA Measurement resolution: 0.001 mA Measuring accuracy: 0.01 \% FS Sampling rate: 200 Hz per input
Period CAN message	200 ms

The measuring probe of the NO_x sensor has the following characteristics:

Feature	Value
Measuring range nitrogen oxide (NO_x)	0 ppm to 1,500 ppm
Measuring accuracy nitric oxide (NO)	See table 1
Response time nitrogen oxide (NO_x)	t_{10-90} : max. 5,300 ms
Cross sensitivity NO_x measurement	Ammonia (NH_3) typ. 100 %
Sensitivity NO_x measurement	Nitrogen dioxide (NO_2) typ. 80 %
Measuring range oxygen (O_2)	0 % to 20.9 %
Measuring accuracy oxygen (O_2)	See table 2
Exhaust gas velocity	Min. 10 m/s
Pressure pulsation	Max. 130 mbar _{peak-to-peak} above 10 Hz
NO_2 correction factor (K_{NO_2})	0.8 (set ex works)



Measuring accuracy

The measuring accuracy of the NO_x sensor can be affected negatively by pressure pulsations above 130 mbar_{peak-to-peak} in the frequency range above 10 Hz. Therefore, only use the NO_x sensor outside this range.

Table 1: Measuring accuracy nitric oxide (NO)

Measurement	Measuring accuracy
NO ≤ 100 ppm	± 10 ppm
100 ppm < NO ≤ 500 ppm	± 10 %
500 ppm < NO ≤ 1,500 ppm	± 15 %

Table 2: Measuring accuracy oxygen (O₂)

Measurement	Measuring accuracy
O ₂ ≤ 5 %	± 2,500 ppm abs
5 % < O ₂ ≤ 20.9 %	± 5 % rel

The I/O communication module of the EasyNO_x EXTENDED package has the following electric characteristics:

Feature	Value
Power supply	Nominal voltage: 24 V DC Operating voltage: 8 V DC to 32 V DC
Binary input	Low level: 0 V Safe high level: supply voltage x 0.5 to 32 V
Binary outputs	Quantity: 3 Plus/ground switching Low level: 0 V High level: corresponds to supply voltage
Analog input	Current range for measured values: 4 mA to 20 mA
Analog output	Output current: 4 mA to 20 mA

4 Product Description

4.1.5 Display

The EasyNO_x display has the following features:

Feature	Value
Screen diagonal	178 mm (7")
Resolution	800 x 480 pixels
Color depth	18 bit (262,144 colors)
Brightness	400 cd/m ² typical
Viewing angle	50°, 70°, 70°, 70° (UDRL)
Touch technology	Projected capacitive multi touch
Backlight service life	50,000 hours typical

4.1.6 Interfaces

The EasyNO_x has the following interfaces:

USB Interface

- Compatible with USB 2.0
- Data rate: 480 Mbit/s (Host)

CAN Bus Interfaces

- Quantity: 2
- Network protocol: CANopen® (CAN1), SAE J1939 (CAN2)
- As per ISO/DIS 11898
- Transmission rate: 250 kbit/s
- Max. wire length 250 m (820')
- The CAN bus interfaces of the EasyNO_x are exclusively intended for communication with devices that are supported by the EasyNO_x.



Operational safety!

The memory card must remain inserted in the EasyNO_x if you use the NO_x monitor. Otherwise you will lose access to the recorded NO_x monitoring data. If the memory card requires mandatory replacement, contact your MOTORTECH contact person (see *Customer Service Information* on page 113).

Memory Card Slots


- Supported memory card types: SDHC, SD, MMC

4 Product Description


4.1.7 Overview Drawings

4.1.7.1 Dimensions

EasyNO_x




4 Product Description




4 Product Description

CAN Bus/NO_x Sensor Module



4 Product Description


I/O Communication Module (EXTENDED Package)



4 Product Description

4.1.7.2 Components


EasyNO_x



Pos.	Description
1	Housing door
2	Touchscreen
3	Housing door lock
4	Cable glands
5	USB port with protective cap

4 Product Description

CAN Bus/NO_x Sensor Module




Pos.	Description
6	CAN bus module
7	Cable glands
8	Grounding cable
9	Connection cable CAN bus module to evaluation unit
10	Evaluation unit of NO _x sensor
11	Evaluation unit connector
12	Connection cable evaluation unit to sensing element
13	Sensing element of NO _x sensor

4 Product Description

4.1.8 Ports/Connections and LEDs


EasyNO_x



Pos.	Description
I	Terminal blocks (see section <i>EasyNO_x</i> on page 49)
II	USB port

4 Product Description

CAN Bus Module



Designation	Function
P1, +, -, G1 P2, +, -, G2	Measurement connections for the thermocouples
P3, +, -, G3	Analog input for a charging pressure or load signal
P4, +, -, G4	Optional analog current input, whose input current can be displayed in the NO _x monitor of the EasyNO _x .
Term Off/On	Slide switch for CAN bus termination
V+, GND	Connection for the supply voltage and for looping through the supply voltage
CAN-L, CAN-H	Port for communication via the CAN bus
ON/CAN	The LED indicates the J1939 status of the CAN bus module: <ul style="list-style-type: none"> Green: The CAN bus module is in "Error Active" state. Glowing green, 4 times flashing red: The CAN bus module is in "Error Passive" state. Red: The CAN bus module is either in "Bus Off" state or there is an error regarding the set bit rate or node ID.

Designation	Function
ERROR	<p>The LED indicates the device status of the CAN bus module:</p> <ul style="list-style-type: none">– Green: The CAN bus module works flawlessly.– Flashes red repeatedly 1 time long and 1 time short: The bit rate is set incorrectly.– Flashes red repeatedly 1 time long and 2 times short: The node ID is set incorrectly.– Flashing steadily red: an unsuitable sensor or no sensor connected
Modul-ID	DIP switches for setting the node ID of the CAN bus module
Baud	DIP switches for setting the bit rate of the CAN bus module

The wiring and configuration of the CAN bus module is described in section *CAN Bus/NO_x Sensor Module* on page 52.

■ 5 Installation Instruction

5.1 Unpacking

Before unpacking, observe the instructions in section *Proper Transport* on page 16.

To prevent condensation from forming in the sensing element of the supplied NO_x sensor, you should avoid any temperature shocks when opening the packaging. Before opening, allow the shipping unit to adjust to the mounting temperature by storing it at mounting temperature for at least one day.

After having opened the packaging, avoid temperature changes of more than $\pm 5\text{ }^{\circ}\text{C}$ ($9\text{ }^{\circ}\text{F}$). The supplied NO_x sensor must not be taken out of its packaging in polluted air and under bad weather conditions (e.g. oil, water, snow, dust, sand, smoke).

Unpack the components of the EasyNO_x system without damaging them and ensure that the operating manual is always within reach of the device and easily accessible. Do not remove the protective cap from the sensing element until you are instructed to do so within this operating manual (see section *Mounting the Sensing Element of the NO_x Sensor* on page 42). Check the contents for completeness and verify that the equipment meets your application requirements.

Scope of Supply

The scope of supply of the EasyNO_x includes:

- EasyNO_x incl. housing and inserted SD card 16 GB
- Sealing plugs for EasyNO_x housing (4x)
- Sealing insert for cable gland M25 on EasyNO_x housing, 3x $\varnothing 7\text{ mm}$ (2x)
- Sealing insert pin for sealing insert opening $\varnothing 7\text{ mm}$ (6x)
- Up to two CAN bus/NO_x sensor modules pre-mounted on a mounting plate, each including
 - Sealing insert pin for cable gland M16, $\varnothing 9.5\text{ mm}$
 - Sealing insert pin for cable gland M12, $\varnothing 7\text{ mm}$ (2x)
 - Welding boss for NO_x sensor
 - Locking screw for welding boss
- Operating manual
- EXTENDED package: up to two I/O communication modules

Optional accessories:

- CAN bus hybrid cable for connecting the CAN bus modules to the EasyNO_x and to the supply power
- Sheath thermocouples with suitable compression fitting
- Manifold pressure sensor

5.2 Mounting of EasyNO_x

The EasyNO_x is typically mounted in the control room on the wall at a suitable accessible location. If there is no control room, the EasyNO_x can also be mounted in the engine room, but not in the immediate vicinity of the engine to protect it from high temperatures and vibrations. The installation location must be selected so that there is sufficient space for maintenance and repair work and the device can be operated without problems. The mechanical specifications of the EasyNO_x must always be complied with (refer to *Mechanical Data* on page 22). The EasyNO_x is not suited for outdoor installation.

For wall mounting, always use the four screw openings on the back of the EasyNO_x housing (see *Dimensions* on page 31). Ensure that the wall has sufficient load-bearing capacity and use fasteners that are suitable for wall mounting. In order to ensure the IP protection class of the EasyNO_x, carry out the fastening in such a way that the screw openings are sufficiently sealed.



Sealing plugs for screw openings

To ensure that the IP protection class of the EasyNO_x is also guaranteed during storage or transport, you can close the four screw openings with the supplied sealing plugs if required.

5.3 Mounting of CAN Bus/NO_x Sensor Module

The CAN bus/NO_x sensor modules must be installed at a suitable location in direct proximity to the engine, but not on the engine. When selecting the mounting locations, pay attention to the maximum available cable lengths and specifications of the individual connection cables. Also observe the mechanical specifications of the CAN bus/NO_x sensor module (see *Mechanical Data* on page 22). Also observe that the J1939 network to which the EasyNO_x and the CAN bus/NO_x sensor modules are connected must comply with the maximum wire length of 250 m (820').

The CAN bus/NO_x sensor module is mounted via the screw openings on the mounting plate (see *Dimensions* on page 31). Use suitable fasteners and make sure that the load-bearing capacity is sufficient at the mounting location.

5 Installation Instruction

5.4 Mounting the Sensing Element of the NO_x Sensor



Risk of suffocation! Risk of poisoning!

Leaks in the exhaust pipe can cause exhaust gases to escape and people in the system room can suffocate or be poisoned. After mounting the sensors, check the tightness of the exhaust pipe.



Operational safety!

To safely mount the NO_x sensor, be sure to observe the following:

- To protect the NO_x sensor and yourself, wear ESD-compliant work gloves. To protect the NO_x sensor against electrostatic discharge, also comply with IEC 61340-5-1 and IEC TR 61340-5-2 in their respective valid versions.
- Under no circumstances touch the probe of the sensing element while mounting.
- If mechanical shock to the sensing element occurs (e.g. drop on the floor), the NO_x sensor must not be used under any circumstances and must be replaced. For this purpose, contact your MOTORTECH contact person (see *Customer Service Information* on page 113).
- The sensing element may be mounted and dismantled a maximum of two times. The electrical connection to the NO_x sensor's evaluation unit may be established and disconnected a maximum of 20 times. After that, proper functioning of the sensor can no longer be guaranteed.



SCR catalytic converter: no monitoring according to VDMA 6299:2019-09

The NO_x monitor of the EasyNO_x does not evaluate the dosing release of the urea solution in an SCR catalytic converter. Thus, the NO_x monitor of the EasyNO_x is not suited for monitoring SCR catalytic converters according to the standard sheet VDMA 6299:2019-09.

The possible mounting positions of the sensing element depend on the catalytic converter type used:


- Oxidizing catalytic converter, three-way catalytic converter: Select a suitable position between exhaust heat exchanger and exhaust gas turbocharger before or after the catalytic converter.
- SCR catalytic converter: Select a suitable position between the catalytic converter and the exhaust heat exchanger.

5 Installation Instruction


Ensure that there is a sufficient distance between the sensing element and the exhaust gas turbocharger. Normally this distance should be at least 1 meter (3.3').

The mounting position of the sensing element must be defined in such a way that no condensation water is able to collect in the protective tube of the sensing element. The possible tilt angles depend on the course of the exhaust pipe. Mounting in a vertical exhaust pipe is not recommended by MOTORTECH.

Horizontal exhaust pipe tilt angles



Vertical exhaust pipe tilt angles



To ensure proper functioning of the connection cable, the minimum bending radius of the connection cable of 20 mm (0.79") must be observed at the mounting position and the angle of the cable outlet at the sensing element grommet must be less than 15° .

The sensing element becomes hot during operation. Therefore, the sensing element must be installed on the exhaust pipe in a suitable location at which people at the plant cannot be burned by it, or an appropriate protection must be installed around the sensing element that prevents contact with it.


Make sure that the engine is switched off while mounting and that the EasyNO_x system is not live. Also make sure that the exhaust pipe has cooled down sufficiently and that there are no exhaust gases in the exhaust pipe.

5 Installation Instruction


The sensing element of the NO_x sensor is screwed into the exhaust pipe via the supplied stainless steel welding boss (material number 1.4301) from MOTORTECH. The supplied locking screw is used for closing the welding boss if you no longer want to use the opening or close it temporarily, and as a welding aid for the welding boss.

Proceed as follows:

1. At the selected mounting position in the exhaust pipe, drill a hole with a diameter of 27 mm \pm 1 mm (1.07" \pm 0.04") into the exhaust pipe.




2. Screw the supplied locking screw into the supplied welding boss and weld the stainless steel welding boss (material number 1.4301) into this hole with a suitable welding filler.



3. To avoid a renewed unscrewing and screwing in of the sensing element, determine the NO₂/NO_x ratio (correction factor K) in the exhaust gas at the mounting position of the sensing element using a suitable calibrated exhaust gas analyzer. More information on this is available in the section *Determining NO₂/NO_x Ratio* on page 45.
4. Remove the protective cap from the probe of the sensing element. Do not pull on the connection cable, but hold the sensing element only by its metal body.
5. Check whether the thread of the sensing element is sufficiently greased. If necessary, re-grease it with high temperature grease. Also make sure that no dirt or dust gets deposited in or on the probe while mounting.
6. Insert the sensing element into the welding boss and screw the sensing element into the welding boss via its hexagon nut by hand first. The outgoing wires must not twist by more than 180°. Therefore counter the sensing element with your hand.

- Then tighten the sensing element over its hexagon nut using a calibrated torque tool with a torque of $50 \text{ Nm} \pm 10 \text{ Nm}$ ($36.9 \text{ lb-ft} \pm 7.4 \text{ lb-ft}$). Make sure that the minimum bending radius of the connection cable of 20 mm (0.79") is observed at the mounting position and that the angle of the cable outlet at the sensing element grommet is less than 15° .



- ▶ The sensing element of the NO_x sensor is mounted.
- Later, when configuring the Easy NO_x , enter the NO_2/NO_x ratio determined above in the *NO_x Thresholds Settings* view of the respective NO_x monitor (see section *Preferences* on page 101).

5.5 Determining NO_2/NO_x Ratio

When the NO_x sensor is mounted for the first time at the installation location and each time the NO_x sensor is replaced, the NO_2/NO_x ratio (correction factor K) in the exhaust gas must be determined at the mounting position of the sensing element. Use a suitable calibrated exhaust gas analyzer and determine the concentration of nitrogen dioxide (NO_2) and nitrogen oxide (NO_x) at the sensing element's mounting position. The correction factor K results from the following equation:

$$K = \text{NO}_2 / \text{NO}_x$$

When configuring the Easy NO_x , enter this value in the *NO_x Thresholds Settings* view for the respective NO_x monitor (see section *Preferences* on page 101).

Always determine the NO_2/NO_x ratio before screwing the sensing element in for the first time and avoid repeatedly screwing the sensing element in and out. Also follow the instructions in the section *Mounting the Sensing Element of the NO_x Sensor* on page 42 when mounting the NO_x sensor for the first time and the instructions in the section *Replacing the NO_x Sensor* on page 116 when replacing the NO_x sensor.

5 Installation Instruction

5.6 Mounting of I/O Communication Module



Assignment of the modules to the engines

Set up your EasyNO_x system in such a way that the first NO_x monitor of the EasyNO_x monitors the first engine and the second NO_x monitor of the EasyNO_x monitors the second engine. Ensure the correct configuration of the EasyNO_x components (CAN bus module, NO_x sensor and with the EXTENDED package also I/O communication module).

In the I/O communication modules of the EXTENDED package, the CAN addresses are unchangeably pre-configured. The MOTORTECH part number (P/N) tells you which CAN address is configured in the I/O communication module.

Part number	CAN address
P/N 63.05.014-01	10 (0x0A)
P/N 63.05.014-02	11 (0x0B)

MOTORTECH recommends that you wire and configure the I/O communication module with CAN address 10 for use with the first NO_x monitor of the EasyNO_x and the I/O communication module with CAN address 11 for use with the second NO_x monitor of the EasyNO_x.

Accordingly, mount the I/O communication module with the appropriate part number on a horizontal top hat rail in the control cabinet of the respective engine. In doing so, observe that the CANopen® network to which the EasyNO_x and the I/O communication modules are connected must comply with the maximum wire length of 250 m (820').

5.7 Installation Locations of Thermocouples



Risk of suffocation! Risk of poisoning!

Leaks in the exhaust pipe can cause exhaust gases to escape and people in the system room can suffocate or be poisoned. After mounting the sensors, check the tightness of the exhaust pipe.


To monitor catalyst operation and to detect the dew point for the NO_x sensor, it is necessary to install a thermocouple in the exhaust pipe at the catalyst outlet at a suitable location. Only use type K thermocouples with the measuring point insulated from the housing. When installing the thermocouples, follow the manufacturer's instructions and ensure that the thermocouples are positioned centrally in the exhaust pipe.

5 Installation Instruction


The following layouts are supported by the EasyNO_x:

- Before and after catalytic converter (*Before & After Cat*)

In this arrangement, mount the thermocouples at equal distances before and after the catalytic converter.




- After catalytic converter (*On After Cat*)



- In two exhaust gas lines after catalytic converter (*Two After Cat*)

The measured values of both thermocouples are used for dew point detection with the NO_x sensor.



5 Installation Instruction

5.8 Installation Location of Manifold Pressure Sensor



Risk of suffocation! Risk of poisoning!

Leaks in the exhaust pipe can cause exhaust gases to escape and people in the system room can suffocate or be poisoned. After mounting the sensors, check the tightness of the exhaust pipe.

If you want to use the absolute charging pressure as an indicator for engine load in normal operation detection and use the NO_x monitoring mode *MAP Naturally Aspirated* or *MAP Turbo* in the EasyNO_x (see section *Preferences* on page 101), a manifold pressure sensor (absolute pressure sensor) 4–20 mA is required.

Install the manifold pressure sensor on the intake side of the engine after the throttle. The installation location must have adequate mechanical strength and must not exceed the specified temperature ranges. Observe the tightening torques as specified by the manufacturer. Comply with the pertinent regulations for wiring. Upon completion of all assembly work, check the system's tightness.

The manifold pressure sensor can be connected directly to the CAN bus module. Alternatively, its signal can be routed via the control cabinet to the CAN bus module. For more information, refer to the section *CAN Bus/NO_x Sensor Module* on page 52.

5.9 Determining Charging Pressure for Normal Operation Detection

This step is mandatory if you want to use the absolute charging pressure as an indicator for engine load in normal operation detection and use the NO_x monitoring mode *MAP Naturally Aspirated* or *MAP Turbo* in the EasyNO_x (see section *Preferences* on page 101). In this case, determine the charging pressure that indicates the start of normal operation on the intake side of your engine (for example 30 % nominal load as per VDMA 6299:2019-09 or as per the engine manufacturer's specifications). In the case of a naturally aspirated engine, this charging pressure must then be undercut, in the case of a turbocharged engine it must be exceeded.

6.1 EasyNO_x



Risk of injury!

The EasyNO_x is designed for operation in circuits with **protected extra-low voltage (PELV)**. The voltages in these circuits must not exceed 50 V AC or 75 V DC.

The EasyNO_x must not be electrically connected to circuits which carry dangerously high voltages or which could lead to a single failure.

Therefore, the following conditions, among others, must be fulfilled:

- The power supply may only be provided from power supply units with safe electrical isolation or from batteries.
- Relays with safe isolation must be used for coupling to circuits that carry dangerous voltages or could carry in the event of a failure.
- All currently applicable standards and regulations must be taken into account.



Operational safety!

The devices of the EasyNO_x system must be operated with closed housings. Otherwise, proper functioning of the devices and compliance with the protection classes cannot be guaranteed.

When the system is powered off, the housings may be opened for wiring and configuration if necessary. When the housing is open, make sure that no moisture forms in the housing.

To wire the EasyNO_x or to change the memory card of the EasyNO_x, you must open the door of the EasyNO_x housing. Using a suitable slotted screwdriver or a screwdriver T25, turn both locks on the right edge of the housing to the open position.

Position closed
(long slot on top)




Position open
(long slot to the left)



6 Wiring and Configuration

Wiring

Do the wiring as follows:



Earth	L +	L -	L -	L +	Shield	Lo	Hi	Com	Com	Hi	Lo	Shield
Power in 24 V _~ max. 10 A		Power out max. 8 A		CAN1 CANopen				CAN2 J1939				

Designation	Function	
Power in 24 V _~	Earth, L +, L -	Clamps for the power supply of the EasyNO _x system (16 V DC to 32 V DC, nominal voltage 24 V DC)
Power out	L -, L +	Clamps for passing through the supply voltage to the first CAN bus/NO _x sensor module (e.g. via the CAN bus hybrid cable from MOTORTECH)
CAN1 CANopen	Shield, Lo, Hi, Com	Clamps for the CAN bus interface CAN1, protocol CAN- open®, for connection to the devices in the CANopen® network including the I/O communication modules of the EasyNO _x EXTENDED package (see <i>CAN Bus Wiring CAN1</i> on page 57)
CAN2 J1939	Com, Hi, Lo, Shield	Clamps for the CAN bus interface CAN2, protocol J1939, for connecting the first CAN bus/NO _x sensor module (e.g. via the CAN bus hybrid cable from MOTORTECH)

Use suitable wire end ferrules (not supplied) for each wire that you place on a clamp.

Use a three-core round cable with a minimum cross section of 1.5 mm² to connect the EasyNO_x system to the power supply. The earth of the EasyNO_x system must be connected to the earth of the system.

6 Wiring and Configuration



Only use shielded CAN wires and connect the shields to the appropriate clamps (*Shield*). Unless you use the CAN bus hybrid cable from MOTORTECH, the shielded CAN cable and the power supply must be routed in parallel. Ensure that the wire cross section of the power supply cable is sufficient depending on its wire length and the number of connected EasyNO_x CAN bus/NO_x sensor modules. Possible wire lengths depending on the wire cross section can be found in the following tables.

Wire cross section 1.5 mm²

Wire length	Minimum supply voltage	
	1 module	2 modules
25 m (82')	18 V DC	20 V DC
50 m (164')	20 V DC	24 V DC

Wire cross section 2.5 mm²

Wire length	Minimum supply voltage	
	1 module	2 modules
25 m (82')	17.3 V DC	18.5 V DC
50 m (164')	18.5 V DC	21 V DC

Insert the supplied sealing inserts and sealing insert pins into the cable glands through which you do not feed any cables. Close all cable glands with a tightening torque of 8 Nm (5.9 lb-ft).

Unless you want to exchange the memory card as well, close the door after wiring the EasyNO_x and turn the locks of the door to the closed position.

6 Wiring and Configuration

Replacement of Memory Card



Operational safety!

The memory card must remain inserted in the EasyNO_x if you use the NO_x monitor. Otherwise you will lose access to the recorded NO_x monitoring data. If the memory card requires mandatory replacement, contact your MOTORTECH contact person (see *Customer Service Information* on page 113).

If necessary, you can replace the supplied memory card with another supported memory card (see section *Interfaces* on page 30). When inserting your memory card, make sure that it is not write-protected by an accidentally flipped write-protect switch. Also note that if you replace the memory card, you will lose access to the previously recorded NO_x monitoring data.

Unless you want to additionally wire the EasyNO_x, close the door after wiring the EasyNO_x and turn the locks of the door to the closed position.

6.2 CAN Bus/NO_x Sensor Module



Operational safety!

The devices of the EasyNO_x system must be operated with closed housings. Otherwise, proper functioning of the devices and compliance with the protection classes cannot be guaranteed.

When the system is powered off, the housings may be opened for wiring and configuration if necessary. When the housing is open, make sure that no moisture forms in the housing.

To wire and configure the CAN bus module and the NO_x sensor, you have to open the housing cover of the CAN bus module. To do so, loosen the four cover screws on the top with a suitable screwdriver and then remove the housing cover. Regard that the cover screws are captively connected to the housing cover.

Use suitable wire end ferrules for each wire that you place on a clamp.

All cables must be fed through a cable gland at a suitable position of the CAN bus module. Insert the supplied sealing inserts and sealing insert pins into the cable glands through which you do not feed any cables. Close the big M16 cable glands with a tightening torque of 3 Nm (2.2 lb-ft) and the small M12 cable glands with a tightening torque of 1.2 Nm (0.9 lb-ft).


After wiring and configuration, put the housing cover back onto the CAN bus module and firmly tighten the four cover screws with a suitable screwdriver until stop so that the CAN bus module is securely closed again.

6 Wiring and Configuration

Grounding

The grounding cable **8** of the CAN bus/NO_x sensor module must be connected to the earth of the system.

Wiring of Thermocouples




Connect the first thermocouple to input 1. Optionally, connect the second thermocouple to input 2 (see section *Installation Locations of Thermocouples* on page 46). Depending on the layout, connect the thermocouples as follows:

Layout	Input 1 (T ₁)	Input 2 (T ₂)
Before and after catalytic converter (<i>Before & After Cat</i>)	Before catalytic converter	After catalytic converter
After catalytic converter (<i>One After Cat</i>)	After catalytic converter	–
In two exhaust gas lines after catalytic converter (<i>Two After Cat</i>)	First exhaust gas line: after catalytic converter	Second exhaust gas line: after catalytic converter

If you do not use input 2, bridge this input with a shorting bridge between the clamps + and –. This prevents the measuring circuit from being disturbed by interfering radiation.

Only use thermocouples with shielded leads. When connecting, make sure that the clamp designation corresponds to the polarity of the thermocouples.


Connect the thermocouples as follows:



Connect the shields of the thermocouple leads with the cable glands. Do not lay the shields inside the CAN bus module.

6 Wiring and Configuration


Wiring of Manifold Pressure Sensor, MAP Signal, Load Signal




Depending on the intended NO_x monitoring mode (see *Preferences* on page 101), connect a manifold pressure sensor 4–20 mA, a MAP signal 4–20 mA or a load signal 4–20 mA to input 3. You can optionally connect another 4–20 mA signal to input 4, whose current value is displayed in the EasyNO_x in the *NO_x Monitoring* view. Note that the large cable gland at the long side of the CAN bus module on the right is not available for input 4 if you connect a second CAN bus module to this module (see the following section *Power Supply / CAN Bus*).

Connect the shields of the wires with the cable glands. Do not lay the shields inside the CAN bus module. No bridges may be set between the measurement inputs.

Connect a manifold pressure sensor as shown in the following illustration. Ensure that the minimum wire cross section of the power supply cable from the manifold pressure sensor is 0.5 mm².




Connect active signal sources 4–20 mA (MAP signal, load signal) as shown in the following illustration. Use shielded wires for connecting active signals 4–20 mA.



6 Wiring and Configuration

Power Supply / CAN Bus



Designation	Function
V+, GND	Clamps for the supply voltage coming from the EasyNO _x or from the first CAN bus module and for passing through the supply voltage to the NO _x sensor and optionally to a second CAN bus module
CAN-L, CAN-H	Clamps for the CAN cable coming from the EasyNO _x or from the first CAN bus module and for passing through the CAN signal to the NO _x sensor and optionally to a second CAN bus module

Note that each clamp is available twofold. If more than one wire has to be connected to a clamp, use suitable double wire end ferrules for a safe connection.

Use these clamps to connect the CAN bus module to the supply voltage and the CAN cable of the EasyNO_x or the first CAN bus module. Use a shielded CAN cable. Connect the shield of the cable with the cable glands. Do not lay the shield inside the CAN bus module.

To pass through the supply voltage and the CAN signal, connect the NO_x sensor and, if needed, a second CAN bus module using these clamps.

The connection cable from the CAN bus module to the evaluation unit of the NO_x sensor is assigned as follows:

Color	Assignment
White	L+
Brown	L-
Green	CAN Lo
Yellow	CAN Hi
Gray	CAN address of the NO _x sensor (see section <i>CAN Addresses NO_x Sensor and CAN Bus Module</i> below)

To avoid coupling of interference signals, make sure that the CAN lines are not laid over the signal lines when wiring.

6 Wiring and Configuration

If you connect a second CAN bus module to the first CAN bus module, pass the power supply and CAN cable to the second CAN bus module through the large cable gland at the long side of the CAN bus module on the right.

CAN Bus Termination

The CAN bus module is the last device in the J1939 network and must be terminated. If you use two CAN bus modules, terminate only the last CAN bus module in the J1939 network. To do so, set the *Term* switch to the desired position using a fine screwdriver.

Termination off

Term
Off/On



Termination on

Term
Off/On



CAN Addresses NO_x Sensor and CAN Bus Module



Assignment of the modules to the engines

Set up your EasyNO_x system in such a way that the first NO_x monitor of the EasyNO_x monitors the first engine and the second NO_x monitor of the EasyNO_x monitors the second engine. Ensure the correct configuration of the EasyNO_x components (CAN bus module, NO_x sensor and with the EXTENDED package also I/O communication module).

For communication with the EasyNO_x via the CAN bus, the correct CAN address must be set for the NO_x sensor. Set the CAN address of the NO_x sensor via the grey wire of the harness to the NO_x sensor as follows.

- First NO_x monitor (*NO_x:1*): Put the grey wire on the *GND* clamp.
- Second NO_x monitor (*NO_x:2*): Do not connect the grey wire.

For communication with the EasyNO_x via the CAN bus, the correct CAN address must be set on the CAN bus module. Set the CAN address of the CAN bus module via the DIP switches *Modul-ID* as follows:

CAN bus module	1	2	3	4	5	6	7	8
First NO _x monitor (<i>NO_x:1</i>)	0	0	0	0	0	0	1	0
Second NO _x monitor (<i>NO_x:2</i>)	1	0	0	0	0	0	1	0

Bit Rate CAN Bus Module

Set the bit rate of the CAN bus module to 250 kbit/s via the DIP switches *Baud*:

1	2	3	4
0	1	1	1

6 Wiring and Configuration



Device Setup EasyNO_x


For each CAN bus/NO_x sensor module you use, add a NO_x monitor (display name NO_x) in the *Device Setup* view of the EasyNO_x (see section *Adding a Device* on page 72). Set up your EasyNO_x system in such a way that the first NO_x monitor (NO_x:1) monitors the first engine and the second NO_x monitor (NO_x:2) monitors the second engine.

6.3 CAN Bus Wiring CAN1

The CAN bus interface CAN1 of the EasyNO_x connects the EasyNO_x to a CANopen® network. This CANopen® network is used to connect the EasyNO_x to the I/O communication modules of the EXTENDED package and the other devices supported by the EasyNO_x.

The wiring of the CAN bus requires three conductors (CAN Hi, CAN Lo and CAN Com). The conductors for CAN Hi and CAN Lo must be twisted wires. At a bit rate of 250 kbit/s, the bus may only have a maximum wire length of 250 m (820') and must be terminated at both ends by a terminating resistor of 120 Ω between the CAN Hi and CAN Lo conductors to prevent reflections.

The following diagram shows an example of the wiring of the EasyNO_x with four other devices:



6 Wiring and Configuration



Common mode voltage in CAN bus

Error-free communication of the devices on the CAN bus is only guaranteed if the voltage levels of the signal lines CAN Hi and CAN Lo are within the range of -2 V to $+7\text{ V}$. If this common mode voltage range is not maintained, use a CAN bus insulator (available from MOTORTECH as accessory) for potential isolation between the interfaces.



CAN bus wiring

Note the following when connecting the CAN bus:

- Each bus end must be fitted with a terminating resistor of $120\ \Omega$ (see drawing).
- The maximum wire length depends on the bit rate:

Bit rate	Maximum wire length	Maximum length of a stub	Maximum length of all stubs
1 Mbit/s	25 m (82')	1.5 m (5')	7.5 m (25')
800 kbit/s	50 m (164')	2.5 m (8')	12.5 m (41')
500 kbit/s	100 m (328')	5.5 m (18')	27.5 m (90')
250 kbit/s	250 m (820')	11 m (36')	55 m (180')
125 kbit/s	500 m (1,640')	22 m (72')	110 m (360')
50 kbit/s	1,000 m (3,280')	55 m (180')	275 m (902')


- Only use cables that are specified by the manufacturer for use in the CAN bus.

The EasyNO_x is delivered with a bit rate set to 250 kbit/s.

6 Wiring and Configuration

6.4 I/O Communication Module

The I/O communication module of the EXTENDED package is designed for wiring via a terminal strip in the switch cabinet. The contacts of the module are assigned as follows:



I Relay connector left

Contact	Wire color	Assignment	Function
1	—	—	Not used
2	Pink	Binary input	Function configurable (see <i>Binary Inputs</i> on page 107)
3	Brown	CAN Lo	CAN connection to the previous device in the CANopen® network
	Green	CAN Lo	CAN connection to the following device in the CANopen® network or connection of terminating resistor
4	—	—	Not used
5	Black	L—	Supply voltage for I/O communication module (8 V DC to 32 V DC, nominal voltage 24 V DC)
6	Red	L+	
7	—	—	Not used
8	Gray	Analog input	Function configurable (see <i>Analog Inputs</i> on page 109)
9	White	CAN Hi	CAN connection to the previous device in the CANopen® network
	Yellow	CAN Hi	CAN connection to the following device in the CANopen® network or connection of terminating resistor

6 Wiring and Configuration

II Relay connector center

Contact	Wire color	Assignment	Function
1	Brown	CAN Lo	Internal CAN connection to right I/O module
2	Black	L–	Pass-through of supply voltage to right I/O module
3	Yellow	Binary output 3	Function configurable (see <i>Binary Outputs</i> on page 108)
4	Red	L+	Pass-through of supply voltage to right I/O module
5	–	–	Not used
6	Orange	Binary output 2	Function configurable (see <i>Binary Outputs</i> on page 108)
7	White	CAN Hi	Internal CAN connection to right I/O module
8	–	–	Not used
9	Purple:	Binary output 1	Function configurable (see <i>Binary Outputs</i> on page 108)

III Relay connector right

Contact	Wire color	Assignment	Function
1	Green	Analog output	Function configurable (see <i>Analog Outputs</i> on page 110)
2	Red	L+	Supply voltage for right I/O module
3	–	–	Not used
4	–	–	Not used
5	–	–	Not used
6	Black	L–	Supply voltage for right I/O module
7	White	CAN Hi	Internal CAN connection to left I/O module
8	–	–	Not used
9	Brown	CAN Lo	Internal CAN connection to left I/O module

Power Supply

The I/O communication modules must be supplied with power via the control cabinet of the respective engine.

6 Wiring and Configuration



CAN Bus and CAN Bus Termination



Common mode voltage in CAN bus

Error-free communication of the devices on the CAN bus is only guaranteed if the voltage levels of the signal lines CAN Hi and CAN Lo are within the range of -2 V to $+7\text{ V}$. If this common mode voltage range is not maintained, use a CAN bus insulator (available from MOTORTECH as accessory) for potential isolation between the interfaces.

The EasyNO_x has a built-in $120\ \Omega$ terminating resistor and must therefore be the first device in the CAN bus.

On the left relay connector **1** of the I/O communication module, the white wire CAN Hi and the brown wire CAN Lo are used for the CAN connection to the previous device on the CAN bus. Use the yellow wire CAN Hi and the green wire CAN Lo of the left relay connector **1** to connect the I/O communication module to the following device in the CAN bus or connect the supplied terminating resistor $120\ \Omega$ to these wires, if the I/O communication module is the last device in the CAN bus.

On the EasyNO_x side, connect the shield of the CAN cable to the *Shield* clamp in the EasyNO_x. On the module side, connect the shield of the CAN cable to the earth of the control cabinet for each I/O communication module. Connect the shields of the CAN cables of all devices in the CAN bus with each other.

Inputs and Outputs

Wire the binary and analog inputs and outputs as needed. Observe that, in the EasyNO_x, you must assign the desired function to the wired inputs and outputs of the I/O communication module before you can use them (see section *Preferences* on page 106). To do this, the respective I/O communication module must have been added as a device in the EasyNO_x (see following section).

Device Setup EasyNO_x

For each I/O communication module you use, add an I/O communication module (display name *BPlus*) in the *Device Setup* view of the EasyNO_x (see section *Adding a Device* on page 72). MOTORTECH recommends that you wire and configure the I/O communication module with CAN address 10 (MOTORTECH part number P/N 63.05.014-01) for use with the first NO_x monitor of the EasyNO_x and the I/O communication module with CAN address 11 (MOTORTECH part number P/N 63.05.014-02) for use with the second NO_x monitor of the EasyNO_x.

7 General Operation

General functions and setting options for the EasyNO_x are described in this chapter. You can find information on the menus of added devices in chapter *Devices* on page 88.



Notice


In this manual, the screenshots and buttons are displayed in day mode. You can find out how to toggle between day and night mode in the section *Start Menu* on page 66.

7.1 Switching on and off the Device

The device is switched on by connection to the power supply and switched off by interrupting the power supply.

7.2 Navigation

The EasyNO_x has a touchscreen, which can be operated directly with the finger or a stylus pen suitable for capacitive touchscreens (not included in scope of supply). The screen comprises the following areas:





7 General Operation



I Title Area

The name of the current view is displayed in the title area of the EasyNO_x. If you are in a device menu, the device and its node ID set in the EasyNO_x are additionally displayed for certain devices. In the NO_x monitor views, a user-defined name is additionally displayed (see section *Preferences* on page 101). In each view, you can view detailed information on the EasyNO_x by tapping on the logo in the upper left corner.

In certain views you can access additional views via the buttons  and .

II Menu Bar

The menu bar on the right-hand side of the screen is always displayed. There is more information in the section *Menu Bar* on page 64.





III Main Window






In the main window, the EasyNO_x is configured and the device menus of added devices are shown.

7 General Operation

7.3 Menu Bar

The menu bar is always displayed and offers the following options and information:

Symbol	Function
 Start	With the <i>Start</i> button you reach the <i>Start Menu</i> . There is more information in the section <i>Start Menu</i> on page 66.
 Back	With the <i>Back</i> button you reach the next higher operating level of the EasyNO _x .
 Tooltip	<p>Information on the buttons and functions can be displayed in pop-up windows. Proceed as follows:</p> <ol style="list-style-type: none">1. In the menu bar, tap the <i>Tooltip</i> button.<ul style="list-style-type: none">▶ The <i>Tooltip</i> button is now activated and framed light blue.2. Tap a button or an area of the display.<ul style="list-style-type: none">▶ A pop-up window with information opens.▶ The <i>Tooltip</i> button is deactivated.3. Tap the screen at any location to close the pop-up window. <p>To get information about other buttons and areas, the <i>Tooltip</i> button must be reactivated.</p>
 Alert	<p>The <i>Alert</i> button in the menu bar can display two states:</p> <ul style="list-style-type: none">– If the button is grayed, there are no messages.– The button is activated when messages are present. <p>To acknowledge messages, tap the activated button.</p> <ul style="list-style-type: none">▶ The <i>Event Log</i> view opens. The filter is automatically set so that only messages of devices that have reported alarms, warnings and errors are displayed.▶ The <i>Alert</i> button is grayed out.▶ In the <i>Start Menu</i>, devices which had a yellow frame now get a green frame again.

Symbol	Function
	<p>This button informs about the status of the access control:</p> <ul style="list-style-type: none"> – <i>Operator, Service, Master</i>: The corresponding access level is set. – <i>Locked</i>: The <i>Read Only</i> access level is set. – <i>Disabled</i>: The access control is disabled. <p>By tapping this button, you can access the <i>Access Control</i> view. There is more information in the section <i>Access Control</i> on page 80.</p>
	<p>Status information of added devices is shown in the lowest field of the menu bar.</p> <p>The communication status symbol provides information on the following states:</p> <ul style="list-style-type: none">  There is a connection to all added devices.  The connection is not established to all added devices.  No other device is connected. <p>The system time is displayed at the very bottom.</p> <p>If you tap the button for the connection status, the <i>Event Log</i> view opens. There is more information in the section <i>Event Log</i> on page 86.</p>

7 General Operation

7.4 Start Menu

The *Start Menu* will be displayed after the EasyNO_x has started. You can access the *Start Menu* any time via the *Start* button in the menu bar.



You have the following options in the *Start Menu*:

Devices

With this button you open the *Device Setup* view, in which you can add new devices and edit device settings. There is more information in the section *Devices* on page 69.

Display

With this button, you open the *Display Configuration* view. Among other things, you can set the language and system time of the EasyNO_x and activate a screen saver. There is more information in the section *Display* on page 76.

Connection

With this button, you open the *Communication Setup* view. You can change the node ID and bit rate of all devices including the EasyNO_x in a CANopen® network to which the EasyNO_x is connected via the CAN bus interface CAN1.

7 General Operation



Night Mode/Day Mode

With this button, you can change the display colors to ensure legibility under various lighting conditions.



Recordings

With this button, you open the *Recorded Files* view. The EasyNO_x currently does not support devices that allow the recording of trend data in the *Device Setup* view.

Help

This button opens the operating manual of the EasyNO_x. There is more information in the section *Help* on page 87.

7 General Operation

Added Devices

The buttons of added devices each contain a device icon, the device name, and for some devices, the node ID configured in the EasyNO_x or a sequential number. The frames of the buttons can take different colors.



The frames of the device buttons have the following meaning:

- Green: There are no errors.
- Yellow: There are one or more messages for the device. Acknowledge the messages via the *Alert* button (see section *Menu Bar* on page 64).
- Purple: No valid software dongle is available for this device (see section *Device Activation* on page 71).
- Red: The device is not connected. Check the connection and connection settings.

Tapping on a device opens the *Main Menu* of the particular device. For information on how to configure devices, see section *Devices* on page 69.

7.4.1 Devices

The *Devices* button in the *Start Menu* opens the *Device Setup* view.



The *Device Setup* view provides the following options:

- **List of Added Devices**
In this field, all added devices are listed. If you tap a device, the class, the node ID or sequence number (depending on the device) and the device logging status are displayed below.
- **Edit**
With the button you open the *Edit Device* dialog. You can find more information in the section *Editing a Device* on page 75.
- **Logging**
With the button you can record data of the selected device to the SD card inserted in the EasyNOx. The EasyNOx currently does not support devices that allow the recording of trend data. This setting does not affect the logging of trend data of an added NOx monitor.
- **Add**
With the button you open the dialog *Add Device*. You can find more information in the section *Adding a Device* on page 72.
- **Delete**
Tap this button to delete an added device. You can find more information in the section *Deleting a Device* on page 75.

7 General Operation

– Device Activation

MOTORTECH provides you with the software dongles which are required to visualize devices in the EasyNO_x. There is more information in the section *Device Activation* on page 71. With the *Back up* button, you can save software dongles to a USB flash drive (e.g. before software updates).

– Binary Outputs

In this area you can activate and deactivate the binary outputs *Warning* and *Error* of the EasyNO_x. In order to use the activated binary outputs *Warning* and *Error* with other devices, they must each be linked to a binary output of the I/O communication module (see section *Preferences* on page 106). The status displays *Warning* and *Error* indicate the switching status of these binary outputs. Additionally, you can switch the binary outputs *Warning* and *Error* on and off for testing purposes. To do so, use the *Test* button to open the *Binary Output Test* window. In this window you can switch the binary outputs and thereby test the behavior of the devices that are connected to the binary outputs. For the NO_x monitor of the EasyNO_x, the warning and error signalling via the binary outputs is predefined.



Operational safety!

The EasyNO_x and the software are not designed for safety-critical applications. The binary inputs and outputs of the EasyNO_x system must not be used for safety-critical purposes.



Operational safety!

Testing the binary outputs affects the connected devices. Before performing tests, make sure that switching the binary outputs will not result in hazards or damage.

– Demo

To access the device-specific pages for demonstration or pre-configuration without the device being connected, you can activate and deactivate the demo mode by tapping the button. The demo mode is indicated in the information bar in the logo by the text *Demo Mode*.



Operational safety!

The demo mode is not a normal operating state of the EasyNO_x. In combination with other devices the EasyNO_x must not be operated in demo mode.

7.4.1.1 Device Activation

For certain devices, activation via software dongles is required in order to use them in the EasyNO_x. Ex works, at least one software dongle is pre-installed in the EasyNO_x so that at least one device is activated. You can add activated devices to the device configuration of your EasyNO_x in the *Device Setup* view (see *Adding a Device* on page 72). You are usually provided with one software dongle for each device you use (e.g. one dongle each for the first and the second NO_x monitor). For additional devices, you can purchase additional software dongles from MOTORTECH (see *Customer Service Information* on page 113) if needed.

Activate a new device as follows:

1. Insert a USB flash drive with a software dongle from MOTORTECH into your EasyNO_x.
2. In the *Device Setup* view, tap *Activate*.
 - ▶ The storage locations available are displayed in a window.
3. Navigate to the desired software dongle with the file extension *.usd* and select it.
4. Tap *Enter*.
 - ▶ The device is activated.
 - ▶ You can add the device in the EasyNO_x (see *Adding a Device* on page 72) and use it.



Activating multiple devices

If you have multiple software dongles for device activation, you can alternatively copy the software dongles into one folder on the USB stick. Then mark this folder in the device activation selection window so that the EasyNO_x reads all software dongles that are in this folder.

7 General Operation

7.4.1.2 Adding a Device



Maximum number of added devices

Simultaneously, a maximum of two NO_x monitors, two I/O communication modules, and one generic device can be integrated in the EasyNO_x.



To add a device, proceed as follows:

1. In the *Device Setup* view, tap the *Add* button.

- ▶ The dialog *Add Device* opens.



This symbol next to a device indicates this device has been activated at least once. You can add the device multiple times until the maximum number of activated devices of this type is reached. For additional devices you need an activation (see section *Device Activation* on page 71).



This symbol next to a device indicates that no activation is required for the device. The device can be added to the device configuration if its maximum number has not been exceeded.



This symbol next to a device indicates that the device has not been activated (see section *Device Activation* on page 71). The device cannot be added to the device configuration.

7 General Operation



2. Select the device. For information on the device *Generic*, read the section *Generic Device* on page 111.
3. Where available, use the arrow keys to set the node ID of the device to be added. The node ID entered must correspond to the node ID of the device.
4. Confirm your entry via the *Save* button.
 - The dialog is closed and you are returned to the *Device Setup* view. The device is displayed in the list of added devices with device class and node ID or sequential number.

5. To add more devices, repeat steps 1 to 4.

7 General Operation

6. When you tap *Start* in the menu bar, the added devices are displayed in the *Start Menu* with node ID (*BPlus*) or sequential number (*NO_x*).



7.4.1.3 Editing a Device

In order to edit the settings for a device, proceed as follows:

1. In the *Device Setup* view, select the device whose settings you want to change from the list of added devices.
2. Tap the *Edit* button.
 - ▶ The dialog for editing devices opens.
3. Set the device and, where applicable, the node ID.
4. Tap *Save*.
 - ▶ The dialog is closed.
 - ▶ The device is displayed with changed settings in the *Device Setup* view and in the *Start Menu*.

7.4.1.4 Deleting a Device

To delete an added device, proceed as follows:

1. In the *Device Setup* view, select the device you want to delete from the list of added devices.
2. Tap *Delete*.
 - ▶ The device is no longer displayed in the *Device Setup* view and in the *Start Menu*.

7 General Operation

7.4.2 Display

The *Display* button in the *Start Menu* opens the following views:

- *Display Configuration*
- *Display Information*

The  and  buttons allow you to switch between the views.

The views are described as follows.

Display Configuration



You have the following options:

- **Language**
Select the desired system language.
- **Temperature Unit**
Select, whether temperatures in the EasyNO_x are to be displayed in °C or in °F. Recordings are also created in the units selected. This setting has no effect on the NO_x monitor. In the NO_x monitor, all temperatures are displayed and recorded in °C.
- **Screen Saver**
Tap *Settings* to configure the screen saver. When the screen saver has been activated, the display is darkened and switched off after a specified time (*Power Save* option) or a slide show starts. In addition, the EasyNO_x is placed on the access level *Read Only* (displayed status *Locked* in the menu bar). By touching the display, a running screen saver is stopped.

- **Pop-ups**
Activate or deactivate pop-ups with information for the user. Important pop-ups, e.g. with information on errors, are always displayed. Pop-ups which e.g. provide information on successful actions can be deactivated.
- **Revert Changes**
Tap *Revert Changes* to restore the status of the last stored configuration. Date and time are not reset.
- **Time Zone**
Tap *Set* to set the time zone.
- **Date, Time** Tap *Set* to set the system time and date. Your configuration options depend on the access level you are logged into (see section *Access Control* on page 80).
- **Configuration**
You have the following options:
 - **Save**
Save the configuration of your EasyNO_x to a USB flash drive. This enables you to easily restore the configuration of your device or transfer it to other devices.
 - **Load**
Load a configuration of your EasyNO_x stored on a USB flash drive. For this, select the desired configuration files via the displayed context menu.
 - **PDF File**
Save a PDF document with information about on configuration of your EasyNO_x to a USB flash drive.
 - **Service**
Creates a service report in English as a PDF document on a USB flash drive. In addition to the configuration information, this service report also contains information on memory usage and a list of events. You can use the service report for service requests to your MOTORTECH contact person (see *Customer Service Information* on page 113).
- **Reboot**
With the *Reboot* button, you carry out a reboot of your EasyNO_x. Unsaved settings will get lost and databases will be closed!

7 General Operation

Display Information


In the *Display Information* view, you can find the following information:

- Display ID
- MOTORTECH serial number
- Arrangement number
- Board support package version
- Software version of your EasyNO_x

EasyNO _x <small>MOTORTECH NO_x MONITORING</small> EasyNO _x		 		 Start
Display ID	<input type="text" value="02509571"/>			 Back
MOTORTECH S/N	<input type="text" value="01234567"/>			 Tooltip
Arrangement No.	<input type="text" value="PV4.00.0000-000-AA-A"/>			 Alert
Board Support Package	<input type="text" value="rocko-7.0-0"/>			 Service
Software	<input type="text" value="1.4.2"/>			 10:49

7.4.3 Connection

The *Connection* button in the *Start Menu* opens the *Communication Setup* view.




The screenshot shows the 'EasyNOx Communication Setup' interface. The title bar includes the 'EasyNOx' logo and 'MOTORTECH NO₂ MONITORING'. The main area is divided into two columns: 'EasyNOx' and 'LSS Commands'. Each column has a 'Node ID' input field with up/down arrows, a 'Bit Rate' section with four buttons (500 kbit/s, 125 kbit/s, 250 kbit/s (selected), and 100 kbit/s), and a 'Save' button. The 'LSS Commands' column also has a 'Send Command' button. On the right side, there is a vertical toolbar with icons and labels: 'Start' (house icon), 'Back' (blue arrow icon), 'Tooltip' (question mark icon), 'Alert' (warning triangle icon), 'Service' (lock icon), and a status bar at the bottom showing a headset icon and the time '17:24'.

In this view, settings can be made for the CANopen® network to which the EasyNO_x is connected via the CAN bus interface CAN1.

7 General Operation

7.5 Access Control

The access control can be accessed in the menu bar via the highlighted button. Depending on the current setting, the button is labeled *Disabled*, *Locked*, *Operator*, *Service* or *Master*.



The access control of the EasyNO_x serves to protect sensitive data and functions. When access control is disabled, there are no restrictions with the exception of the NO_x monitor views. With enabled access control (see section *Enabling/Disabling Access Control* on page 82) four access levels with different rights are available (see table below). Note that the NO_x monitor views can only be opened when access control is enabled and you need at least the rights of the access level *Operator* to open these views.

Access level	Rights
Read Only (displayed status in the menu bar: <i>Locked</i>)	<ul style="list-style-type: none">– Switch between day and night mode– Activate and deactivate pop-ups
Operator	<ul style="list-style-type: none">– Read Only rights– Access to NO_x monitor– Export logs and report of NO_x monitor to a USB flash drive– Display configuration

Access level	Rights
Service	<ul style="list-style-type: none">– Operator rights– Change settings of the following devices:<ul style="list-style-type: none">– NO_x monitor– I/O communication module– Complete display configuration– Activate devices
Master	<ul style="list-style-type: none">– Service rights– Set system time and system date– Enable/Disable access control– Reset all PINs– Firmware Update



Access to locked functions

If you would like to access a function with enabled access control, which exceeds your currently set rights, you will be prompted to enter the PIN for the access level required.

7 General Operation

7.5.1 Enabling/Disabling Access Control



Access control in as-delivered state

In as-delivered state, the access control is not enabled and all PINs are set to 0000. After enabling the access control, assign an individual PIN for each access level including *Master* (see *Changing the PIN* on page 84).

Enabling Access Control

Enable the access control for all access levels as follows:

1. Tap the *Enable Control* button.
 - ▶ You are prompted to enter the PIN for the access level *Master*.
2. Enter the PIN for the access level *Master* and tap *OK*.
 - ▶ Access control for all access levels is enabled.
 - ▶ You are logged in as *Master*.
 - ▶ The *Logout* button is activated.
 - ▶ The *Disable Control* button is activated.

If necessary, you can log on for a different access level. Refer to the section *Logging in and Logging out* on page 83.

Disabling Access Control



Disabling access control

If the access control is not to be used for a longer period of time, we recommend that you write down the Master PIN or reset all PINs to 0000 before disabling the access control. A renewed enabling of the access control is only permitted with the Master PIN. If you have forgotten the Master PIN, you must contact MOTORTECH for a reset of all PINs (see *Resetting the PINs* on page 84).

Disable the access control for all access levels as follows:

1. Tap the *Disable Control* button.
 - ▶ You are prompted to enter the PIN for the access level *Master*.
2. Enter the PIN for the access level *Master* and tap *OK*.
 - ▶ The *Disabling Access Control* dialog window appears.

3. Observe the note in the *Disabling Access Control* dialog window. If you are certain that you want to disable access control, answer the displayed question by tapping *Yes*.
 - ▶ Access control for all access levels is disabled.
 - ▶ In the menu bar the condition *Disabled* is displayed.
 - ▶ The buttons *Login* and *Logout* are deactivated.
 - ▶ The *Enable Control* button is activated.

7.5.2 Logging in and Logging out

With enabled access control, you can log on for the access levels *Operator*, *Service* and *Master*.

Logging in

Log in as follows for the desired access level:

1. From the drop-down list under *Access Level*, select the desired access level (*Operator*, *Service* or *Master*).
2. Tap the *Login* button.
 - ▶ You will be prompted to enter the corresponding PIN.
3. Enter the PIN and tap *OK*.
 - ▶ You have now logged into the desired access level and can use the associated functions.
 - ▶ The access level set is displayed in the menu bar.

Logging out



Automatic logout

You are automatically logged out of the access levels *Operator*, *Service* or *Master*,

- if you have not entered anything for six minutes.
- if for six minutes only functions of lower access levels are used.
- if the screen saver is switched on.

The EasyNO_x is then placed on the access level *Read Only* with the displayed status *Locked*.

There are two options for logging out manually from the access levels *Operator*, *Service*, or *Master*:

■ 7 General Operation

Option 1:

Leave the currently set access level with the *Logout* button in the *Access Control* view.

- ▶ In the menu bar the condition *Locked* is displayed.
- ▶ The set access level is *Read Only*.
- ▶ The *Logout* button is deactivated.
- ▶ The *Login* button is activated.

Option 2:

1. From the drop-down list under *Access Level* in the *Access Control* view, select a different access level (*Operator*, *Service* or *Master*).
2. Tap the *Login* button.
 - ▶ You will be prompted to enter the corresponding PIN.
3. Enter the PIN and tap *OK*.
 - ▶ You have now logged into the desired access level and can use the associated functions.
 - ▶ The access level set is displayed in the menu bar.

7.5.3 Changing the PIN

Change the PIN of the access levels *Operator*, *Service* or *Master* as follows:

1. Log on for the access level (*Operator*, *Service* or *Master*) whose PIN you want to change (see section *Logging in and Logging out* on page 83).
2. Tap the *Change PIN* button.
 - ▶ You are prompted to enter the current PIN for the active access level.
3. Enter the current PIN and tap *OK*.
 - ▶ You are prompted to enter a new PIN for the active access level.
4. Enter the new four-digit PIN and tap *OK*.
5. In the *Confirm New PIN* field, re-enter the new four-digit PIN and tap *OK*.
 - ▶ The PIN of the active access level was changed.

7.5.4 Resetting the PINs

Forgotten Operator PIN / Service PIN

If you have forgotten the PIN for the access levels *Operator* or *Service*, contact the Master. The latter can reset all PINs to the value *0000* as described in the following. Afterwards, new PINs must be assigned for all access levels.

Resetting All PINs

The authorization for the access level *Master* allows you to reset the PINs of all access levels:

1. Log in for the access level *Master* (see section *Logging in and Logging out* on page 83).
2. In the area *Master Only*, tap on *Reset All PINs*.
 - ▶ All PINs are reset to the value 0000.



Assign new PINs!

After resetting the PINs, new PINs must be assigned for all access levels to guarantee maximum security.

Master PIN Forgotten

If you have forgotten the Master PIN, you must apply for a PIN Reset Authorization Key from MOTORTECH. With this key you can reset all PINs without authorization for the access level *Master*.

Requesting Key

Request the key from MOTORTECH as follows:

1. Tap the *Request Key* button.
 - ▶ A dialog window with the new and actual PIN Reset Request Key opens.
 - ▶ Send the new PIN Reset Request Key (*New PRRK*) to your MOTORTECH contact person.
2. Tap the *Confirm Request* button.
 - ▶ MOTORTECH sends you a PIN Reset Authorization Key based on *New PRRK*. Note that the PIN Reset Authorization Key is only valid for a limited period of time.

Entering Key

Enter the key from MOTORTECH in your EasyNO_x as follows:

1. Insert the USB flash drive containing the MOTORTECH key into your EasyNO_x.
2. In the area *PIN Reset with Key*, tap the button *Reset All PINs*.
 - ▶ The storage locations available are displayed in a window.
3. Navigate to the desired PIN Reset Authorization Key (file extension *.prak*) and select it.
4. Tap the *Enter* button.
 - ▶ All PINs are reset to the value 0000.



7 General Operation


7.6 Event Log


If you tap on the status information field in the menu bar (see marking), the *Event Log* view opens. In this view you get messages concerning the EasyNOx.


EasyNOx
MOTORTECH NO_x MONITORING


EasyNOx
Event Log






Start


Back


Tooltip


Alert


Service


11:23

Date	Time	ID	Device	Message
2020-10-20	09:33:31	67	EasyNOx	Access control enabled.
2020-10-20	09:33:31	1	NOx	No enable input defined.
2020-10-20	09:33:31	502	NOx	Access control not active.
2020-10-20	09:33:31	67	EasyNOx	Started 1.4.1
2020-10-20	09:30:43	67	EasyNOx	Demo mode switched on
2020-10-20	09:30:42	67	EasyNOx	Access level set to Service.
2020-10-20	09:28:03	67	EasyNOx	Access control enabled.
2020-10-20	09:28:03	1	NOx	No enable input defined.
2020-10-20	09:28:03	502	NOx	Access control not active.
2020-10-20	09:28:03	67	EasyNOx	Started 1.4.1
2020-10-19	13:39:58	67	EasyNOx	Demo mode switched on
2020-10-19	13:39:55	67	EasyNOx	Access level set to Service.
2020-10-19	13:39:18	67	EasyNOx	Access control enabled.
2020-10-19	13:39:18	1	NOx	No enable input defined.
2020-10-19	13:39:18	502	NOx	Access control not active.

The following data is displayed: date (YYYY-MM-DD) and time (HH:MM:SS) of the entry, node ID or internal sequential number of the device, device name and the accompanying message. A maximum of 1,000 messages are displayed and stored by the EasyNOx. Older messages are deleted.

In the title area, two buttons are displayed. The symbols on the buttons change depending on their setting and are described in the following.

Filter Button

The button's appearance has the following meaning:



No filters are active. All entries are displayed.



Filters are active. Only certain entries are displayed.

To set or change filters, tap the *Filter* button. The *Filter Settings* dialog window appears. Select time and node IDs of the entries you want to display. If you select none of the listed node IDs, the entries for all listed node IDs are displayed. Confirm your selection with *OK*. Tap *Clear* to reset the filters.

7 General Operation



Automatic Scrolling Button

The button's appearance has the following meaning:



Automatic scrolling is inactive.



Automatic scrolling is active.

To activate and deactivate automatic scrolling, tap the *Automatic Scrolling* button. When the function is activated, the EasyNO_x scrolls automatically to newly registered entries.

You have the following options for navigating in the list:

- Tap in the list and drag the displayed list section in the desired direction.
- Double-tap in a border area of the list (top, bottom, left, right) to jump to the end of the respective border area.
- Tap and hold in a border area of the list (top, bottom, left, right) to scroll in the desired direction.
- Move one of the scroll bars to scroll in the desired direction.

7.7 Help

You can access the operating manual of the EasyNO_x as follows:

- *Help* button in *Start Menu*
- *Help* button in the *NO_x Main Menu* view of an added NO_x monitor
- *Help* button in *Main Menu* of an added I/O communication module

In the browser, tap on the appropriate links, and then use the bars on the right side of the screen to scroll and the buttons for navigation:

- **Start**
Use this button to go to the first page of the operating manual.
- **Back**
Use this button to go to the previously displayed page of the operating manual.
- **Close**
Use this button to exit the Help menu.

8 Devices

This chapter describes the device menus of the devices that can be added in the EasyNO_x.

Information about adding devices can be found in the section *Devices* on page 69.

You can access the device menus of added devices via the corresponding buttons in the *Start Menu*.

8.1 NO_x Monitor



NO_x monitor: enable access control

The views of the NO_x monitor can only be opened when access control is enabled. In order to open these views, you need at least the rights of the access level *Operator*. For more information, read the section *Access Control* on page 80.



Automatic exit from NO_x monitor

If you do not make any entries for 6 minutes or the screen saver switches on, the views of the NO_x monitor are automatically exited and the access level is set to *Read Only* (displayed state in the menu bar *Locked*).

This section describes the functions and views of an added NO_x monitor.

8.1.1 Main Menu

The main menu of an added NO_x monitor can be opened in the Start Menu via the NO_x button.




The main menu has the following buttons:



- **Overview**
The button provides information about the current status of the NO_x monitor and provides access to the current trend of measured values. There is more information in the section *Overview* on page 90.
- **History**
The button can be used to display the trend of the logged measured values for each day. There is more information in the section *History* on page 95.
- **Logbook**
The button provides access to logbook of the NO_x monitor. There is more information in the section *Logbook* on page 97.
- **Export**
This button provides access to the export function of the NO_x monitor, which allows you to export logged data and the logbook to a USB flash drive. There is more information in the section *Export* on page 99.
- **Preferences**
The button provides access to the settings of the NO_x monitor. There is more information in the section *Preferences* on page 101.

8 Devices

– Operator

The button provides access to the window *Information on Operator*. Fill in the appropriate information in this window. The operator information stored here is valid for both NO_x monitors of the EasyNO_x and appears in the PDF report, which can be exported to a USB flash drive using the export function of the NO_x monitors.



Information on Operator	
Owner/Operator	Company
Contact	Jane Doe
Street	Mainstreet 5
Postal Code	102-ea
City	London
Site	CHP
<div> OK  Cancel</div>	

– Help

This button opens the operating manual of the EasyNO_x. There is more information in the section *Help* on page 87.

8.1.2 Overview

The *Overview* button in the main menu of an added NO_x monitor opens the following views:

- *NO_x Monitoring*
- *NO_x Trends*

The  and  buttons allow you to switch between the views.

The views are described as follows.

NO_x Monitoring



This view displays the current status of the NO_x monitor. The view varies depending on the set NO_x monitoring mode. The various parameters of the NO_x monitor can be set in the *NO_x Thresholds Settings* view (see section *Preferences* on page 101). If one of the entries shows the value *A*, the value is outside of the specified range.

The following information is provided:

- **Dew Point**
The blue status display shows that the temperature in the exhaust pipe at the catalyst outlet is above the dew point of the NO_x sensor. For thermocouple layout *Two After Cat* (see *Preferences* on page 101), this condition must be met in both exhaust gas lines.
- **Normal Operation**
The green status display shows that normal operation is detected.
- **24h Average**
This entry shows the provisional daily average of the nitrogen oxide measured values converted in accordance with VDMA 6299:2019-09 since 0:00 hrs CET (UTC+1) of the current day. If the entry is grayed, the conditions for averaging are not met.
- **Trend**
The status display indicates that the provisional daily average of the nitrogen oxide concentration exceeds certain thresholds.
 - Red: The provisional daily average currently exceeds the configured level limit.
 - Yellow: The provisional daily average currently exceeds the configured warning level.


8 Devices

- Gray: The provisional daily average currently does not exceed any of the configured thresholds.
- **Δ Temperature**
This entry shows the current temperature difference of the exhaust gas between the catalyst inlet and outlet. The entry is available if the layout *Before & After Cat* is set for exhaust gas temperature monitoring in the EasyNO_x. The temperature at the catalyst inlet is subtracted from the temperature at the catalyst outlet. The background colors of the entry have the following meaning:
 - Red: The configured temperature difference maximum is exceeded.
 - Blue: The configured temperature difference minimum is undercut.
 - White (day mode) or black (night mode): The current temperature difference is within the configured permissible range.
- **Nitrogen Oxide Measured Value Display (Analog)**
 - Red pointer
In normal operation display of the current nitrogen oxide measured value converted to standard volume with a reference oxygen content of 5 % according to VDMA 6299:2019-09
 - Blue pointer
Display of the provisional daily average of the nitrogen oxide measured values converted according to VDMA 6299:2019-09 since 0:00 hrs CET (UTC+1) of the current day, as soon as nitrogen oxide measured values have been measured in normal operation.
- **Nitrogen Oxide Measured Value Display (Digital)**
In normal operation display of the current nitrogen oxide measured value converted according to VDMA 6299:2019-09
- **T₁, T₂**
Display of the currently measured exhaust gas temperature. T₂ is not available if the layout *Before & After Cat* is set for exhaust gas temperature monitoring in the EasyNO_x. The background colors of the entry have the following meaning:
 - Red: The configured overtemperature has been exceeded at the respective measuring point.
 - White (day mode) or black (night mode): The currently measured exhaust gas temperature is below the configured overtemperature at the respective measuring point.
 - Purple: The measured value is not transmitted via the CAN bus.

- **MAP / Load / In 3**
The displayed entry depends on the selected monitoring mode. If the background of the respective entry is purple, the measured value is not transmitted via the CAN bus.
 - **MAP**
This entry is displayed in the NO_x monitoring modes *MAP Naturally Aspirated* and *MAP Turbo* and shows the current charging pressure measured via input 3 of the respective CAN-Bus module.
 - **Load**
This entry is displayed in the NO_x monitoring modes *Load on CAN Module* and *Load via CANopen* and shows the current load signalled via the respective analog input.
 - **In 3**
This entry is displayed in the NO_x monitoring modes *Off*, *Recording Only* and *Start/Stop via CANopen* and shows the current input current at input 3 of the respective CAN bus module.
- **In 4**
This entry shows the current input current at input 4 of the respective CAN bus module. If the background of the entry is purple, the measured value is not transmitted via the CAN bus.
- **NO_x**
Display of the current nitrogen oxide measured value from the connected NO_x sensor. If the background of the entry is purple, the measured value is not transmitted via the CAN bus.
- **O₂**
Displays the current oxygen measured value from the connected NO_x sensor. If the background of the entry is purple, the measured value is not transmitted via the CAN bus.
- **Op**
Shows the normal operation hours registered so far by the EasyNO_x for the current logging year.
- **Alm**
Failure hour counter, which shows the number of hours the daily average NO_x concentration in the current calendar year has been above the configured level limit so far after the end of a day. If the final average at the end of a day exceeds the configured level limit, the detected normal operation hours of that day are added to the failure hour counter. At the beginning of a new calendar year, the failure hour counter is automatically reset to 0 hours. The background colors of the entry have the following meaning:
 - Red: The configured time limit of the failure hour counter is exceeded.
 - Yellow: The configured warning level of the failure hour counter is exceeded.
 - White (day mode) or black (night mode): None of the configured thresholds is exceeded.

8 Devices

NO_x Trends



In the *NO_x Trends* view, you get information about the current trend of the measured values and the provisional nitrogen oxide daily average for the last 10 minutes. You can hide or show individual trends using the legend.

The following trends are displayed:


- **O₂ %**
Trend of the oxygen measured value from the connected NO_x sensor
- **NO_x ppm**
Trend of the nitrogen oxide measured value from the connected NO_x sensor
- **NO_x**
Trend of the nitrogen oxide measured value, converted to standard volume with a reference oxygen content of 5 % in mg/Nm³ according to VDMA 6299:2019-09
- **NO_x ø**
Trend of the provisional daily average of the nitrogen oxide measured values converted according to VDMA 6299:2019-09 since 0:00 hrs CET (UTC+1) of the current day in mg/Nm³
- **T1, T2**
Trend of the measured exhaust gas temperatures

– MAP / Load / ---

The displayed trend depends on the selected monitoring mode. *MAP* displays the trend of the measured charging pressure in the NO_x monitoring modes *MAP Naturally Aspirated* and *MAP Turbo*, *Load* in the NO_x monitoring modes *Load on CAN Module* and *Load via CANopen* the trend of the signalled load. Three dashes (---) appear in the NO_x monitoring modes *Off*, *Recording Only* and *Start/Stop via CANopen* and no trend is displayed.

8.1.3 History

The *History* button in the main menu of an added NO_x monitor opens the NO_x History view.



In this view, you can display the trend of the logged measured values for each individual day.

The and buttons allow you to switch between the days.

You can hide or show individual trends using the legend.

Three parameter groups are available. Tap into the trend graph to select the desired group.

8 Devices

Depending on the selected parameter group, the following trends are displayed:

Parameter group	Parameters	Description
NO _x	NO _x [ppm]	Daily trend of the nitrogen oxide measured value from the connected NO _x sensor
	NO _x [mg/Nm ³]	Daily trend of the nitrogen oxide measured value converted to standard volume with a reference oxygen content of 5 % according to VDMA 6299:2019-09
	NO _x av [mg/Nm ³]	Daily trend of the provisional daily average of the nitrogen oxide measured values converted according to VDMA 6299:2019-09
Temperature	T1 [°C]	Trend of the measured exhaust gas temperature
	T2 [°C]	Trend of the measured exhaust gas temperature
Current	In3 [mA]	Trend of the measured input current at input 3 of the respective CAN bus module
	In4 [mA]	Trend of the measured input current at input 4 of the respective CAN bus module

8.1.4 Logbook

The *Logbook* button in the main menu of an added NO_x monitor opens the *Logbook* view. In the logbook, the EasyNO_x logs events from the respective NO_x monitor. You can also create user-defined entries in the logbook.

Date	Time	Category	Message
2020-10-27	09:01:21	CONFIGURATI	No enable input defined.
2020-10-26	10:44:30	CONFIGURATI	Service set Scaling Max. from 3000
2020-10-26	10:44:30	CONFIGURATI	Service set Mode Limit from 1400 t
2020-10-26	10:44:30	CONFIGURATI	Service set Mode from MAP Turbo to
2020-10-23	11:28:58	WARNING	SD-Card changed. Serial number fro
2020-10-23	11:05:54	CONFIGURATI	Service set Serial Number from to
2020-10-23	11:05:54	CONFIGURATI	Service set Mode Limit from 450 to
2020-10-23	11:05:54	CONFIGURATI	Service set Mode from Off to MAP T
2020-10-20	09:54:10	CONFIGURATI	Service set Engine Name from Motor
2020-10-20	09:54:10	CONFIGURATI	Service set Scaling Max. from 0 to
2020-10-20	09:54:10	CONFIGURATI	Service set Mode Limit from 0 to 1
2020-10-20	09:54:10	CONFIGURATI	Service set Mode from Start/Stop v
2020-10-20	09:40:05	CONFIGURATI	No enable input defined.
2020-10-20	09:37:14	CONFIGURATI	No enable input defined.
2020-10-20	09:33:31	CONFIGURATI	No enable input defined.

For each entry the date (YYYY-MM-DD), time (HH:MM:SS), category, and the related message are displayed. Note that this view is continuously updated and displays at most the last 1,000 entries, although the logbook may contain more entries. To display older entries, you can filter the period to be displayed (see section *Filter Button* below).

In the title area, three buttons are displayed. The symbols on the middle and right button change depending on their settings. The buttons are described as follows.


Custom Entry Button

To add custom entries to the logbook, tap the following button:



8 Devices


The dialog window *Add Entry to Logbook* appears.



First, specify the creator of the logbook entry under *Name/Organization*. Then under *Measure*, use the drop-down list to select the type of measure (e.g. Service, Faults, Maintenance) for the logbook entry. The selection made here determines the available entries under *Event*. Then under *Event*, select the relevant event from the drop-down list (e.g. Regular engine maintenance performed, Engine/generator/cooling defective). If necessary, you can enter additional information about the logbook entry under *Description*. To save your logbook entry, tap on *OK*. To discard the logbook entry, tap on *Cancel*.



Events with lock icon

Events marked with a lock icon  cannot be entered in the logbook with the rights of your access level. If you select such an event, you will be prompted to log in for the required access level.

Filter Button

The button's appearance has the following meaning:



No filters are active. All entries are displayed.



Filters are active. Only certain entries are displayed.

To filter the logbook entries, tap the *Filter* button. The dialog window *Logbook Filter* appears. Select the period and the categories of the entries to be displayed. Regard any dialog messages that you may get when setting the filters. Confirm your selection with *OK*.

Automatic Scrolling Button

The button's appearance has the following meaning:



Automatic scrolling is inactive.



Automatic scrolling is active.


To activate and deactivate automatic scrolling, tap the *Automatic Scrolling* button. When the function is activated, the EasyNO_x scrolls automatically to newly registered entries.

You have the following options for navigating in the list:

- Tap in the list and drag the displayed list section in the desired direction.
- Double-tap in a border area of the list (top, bottom, left, right) to jump to the end of the respective border area.
- Tap and hold in a border area of the list (top, bottom, left, right) to scroll in the desired direction.
- Move one of the scroll bars to scroll in the desired direction.

8.1.5 Export

The *Export* button in the main menu of an added NO_x monitor opens the *NO_x Export* view.



This view allows you to copy logged data and the logbook of the NO_x monitor to a USB flash drive inserted in the EasyNO_x.

The file overview shows you the logs available on the device. Move the scroll bar to scroll up or down when necessary. Select the desired calendar year via the respective year number in blue letters. Select the desired day log via the respective date in black letters. Select the compressed year log via the year number in green letters.

When copying to the USB flash drive, the progress bar below the buttons shows the copying progress and other information about the copying process.


■ 8 Devices

You have the following options:

- **Copy**
This function is available for service purposes and creates a 1:1 copy of the desired log on the USB flash drive. This 1:1 copy cannot be read or processed by other devices.
- **CSV Export**
Select the desired log and use the button to create a copy of the log as a CSV file on the USB flash drive. On a PC, the CSV file can be opened with an editor, for example, or further processed with a spreadsheet. The CSV file is saved in the following format:
 - Character set: UTF-8
 - Separator: Tab
 - Decimal separator: Dot
- **Report**
Use this button to create a report as a PDF file on the USB flash drive, which, among other information, summarizes the measurement results of the selected calendar year and contains the logbook. The operator information contained in the report can be specified in the *NO_x Main Menu* view using the *Operator* button (see section *Main Menu* on page 89). No report can be generated without specified operator information.
- **Up**
Use this button to return to the calendar year selection in the file overview.
- **Abort**
Use this button to cancel an ongoing copying process to the USB flash drive.

8.1.6 Preferences

The *Preferences* button in the main menu of an added NO_x monitor opens the *NO_x Thresholds Settings* view.



EasyNO_x Engine 1
MOTORTECH NO_x MONITORING

NO_x Thresholds Settings

Mode	MAP Turbo	Name	Engine 1
Scaling Min.	0 mbar	Serial Number	140253
Scaling Max.	3000 mbar		
MAP >	800 mbar		
K	0.2	Layout	Before & After
KNO ₂	0.8	Overtemperatur 1	580 °C
		Undertemperatur 1	250 °C
		Overtemperatur 2	590 °C
		Undertemperatur 2	250 °C
Level Limit	600 mg/Nm ³	Min. Δ Temperature	-20 K
Level Warning	500 mg/Nm ³	Max. Δ Temperature	20 K
Time Limit	400 h		
Time Warning	350 h		

Start
Back
Tooltip
Alert
Service
10:46

Note that changes in this view are not saved and applied by the NO_x monitor until you exit the view. Also note that you can only edit the NO_x monitoring parameters after you have entered the serial number of the engine to be monitored under *Serial Number*. You can make the following settings:

- **Mode**
Use the drop-down list to set the NO_x monitoring mode:
 - **Off**
NO_x monitoring is disabled. The nitrogen oxide and oxygen measured values of the NO_x sensor are not recorded.
 - **Recording Only**
The nitrogen oxide and oxygen measured values from the NO_x sensor are recorded, but NO_x monitoring is deactivated.
 - **MAP Naturally Aspirated**
For normal operation detection of the NO_x monitor the absolute charging pressure of a naturally aspirated engine serves as an indicator for the engine load. For this purpose, a manifold pressure sensor must be connected to input 3 of the respective CAN bus module (see *CAN Bus/NO_x Sensor Module* on page 52).

8 Devices

- **MAP Turbo**
For normal operation detection of the NO_x monitor the absolute charging pressure of a turbo engine serves as an indicator for the engine load. For this purpose, a manifold pressure sensor must be connected to input 3 of the respective CAN bus module (see *CAN Bus/NO_x Sensor Module* on page 52).
- **Load on CAN Module**
The NO_x monitor detects normal operation by means of the load signal connected to input 3 of the respective CAN bus module (see *CAN Bus/NO_x Sensor Module* on page 52).
- **Load via CANopen**
The NO_x monitor detects normal operation by means of the load signal connected to the analog input of the I/O communication module. For this purpose, the function *Load Input for NO_x* must be assigned to the analog input of the respective I/O communication module (see *Analog Inputs* on page 109).
- **Start/Stop via CANopen**
The NO_x monitor receives the release for normal operation from the master control via a binary signal connected to the binary input of the I/O communication module. For this purpose, the function *Normal Operation Release for NO_x* must be assigned to the binary input of the respective I/O communication module (see *Binary Inputs* on page 107).
- **Scaling Min., Scaling Max.**
Via these entries you can specify the measuring value range of the absolute manifold pressure sensor in the NO_x monitoring modes *MAP Naturally Aspirated* and *MAP Turbo*. Enter under *Scaling Min.* the measured value of the sensor at 4 mA and under *Scaling Max.* at 20 mA. The values in-between are linearly interpolated.
- **MAP < / MAP > / Last / ---**
The entry displayed at this point depends on the set NO_x monitoring mode:
 - **MAP <**
In the NO_x monitoring mode *MAP Naturally Aspirated* you set the absolute charging pressure which must be undercut for normal operation detection (see *Determining Charging Pressure for Normal Operation Detection* on page 48).
 - **MAP >**
In the NO_x monitoring mode *MAP Turbo* you set the absolute charging pressure which has to be exceeded for normal operation detection (see *Determining Charging Pressure for Normal Operation Detection* on page 48).
 - **Load**
In the NO_x monitoring modes *Load on CAN Module* and *Load via CANopen*, you specify the load that indicates the start of normal operation of your engine (for example 30 % nominal load as per VDMA 6299:2019-09 or as per the engine manufacturer's specifications).

- 103

8 Devices

- **Layout**

Use the drop-down list to set the layout of the thermocouples (see *Installation Locations of Thermocouples* on page 46):

- **Before & After Cat**

One thermocouple respectively measures the exhaust gas temperature before and after the catalytic converter.

- **One After Cat**

One thermocouple measures the exhaust gas temperature after the catalytic converter.

- **Two After Cat**

In engines with two exhaust gas lines, one thermocouple after each catalytic converter measures the exhaust gas temperature.

- **Overtemperature 1 / 2**

Specify respectively the exhaust gas temperature which must not be exceeded in the exhaust pipe at the respective measuring point ($1=T_1$, $2=T_2$).

- **Undertemperature 1 / 2**

Specify respectively the exhaust gas temperature which must not be undercut in the exhaust pipe at the respective measuring point ($1=T_1$, $2=T_2$).

- **Min. Δ Temperature, Max. Δ Temperature**


If you have selected the layout *Before & After Cat* for exhaust gas temperature monitoring, you must also specify the permissible temperature difference range of the exhaust gas between the catalyst inlet and outlet. A positive temperature difference stands for a correspondingly higher temperature at the outlet compared to the inlet. A negative temperature difference stands for a correspondingly lower temperature at the outlet compared to the inlet.

8.2 I/O Communication Module

This section describes the functions and views of an added I/O communication module.

8.2.1 Main Menu

The main menu of an added I/O communication module can be opened in the Start menu via the *BPlus* button.



The main menu has the following buttons:

- **Binary Inputs**
The button opens the *Binary Inputs* view. In this view, a green status display in the *Status* column shows that the corresponding binary input in the *Ch.* (Channel) column is closed.
- **Binary Outputs**
The button opens the *Binary Outputs* view. In this view, a green status display in the *Status* column shows that the corresponding binary output in the *Ch.* (Channel) column is switched.
- **Analog Inputs**
The button opens the *Analog Inputs* view. In this view, the incoming signal that is present at the corresponding analog input in the *Ch.* (Channel) column is displayed as raw value in the *Value* column.
- **Analog Outputs**
The button opens the *Analog Outputs* view. In this view, the outgoing signal that is output by the I/O communication module at the corresponding analog output in the *Ch.* (Channel) column is displayed as raw value in the *Value* column.

8 Devices

- [Preferences](#)


The button provides access to the settings of I/O communication module. There is more information in the section *Preferences* on page 106.

- [Help](#)

This button opens the operating manual of the EasyNOx. There is more information in the section *Help* on page 87.

8.2.2 Preferences

The *Preferences* button in the main menu of an added I/O communication module opens the *Preferences* view.



The *Preferences* view contains the following buttons:

- [Binary Inputs](#)

Use the button to open a view in which you can set the function of the binary input for the respective I/O communication module. There is more information in the section *Binary Inputs* on page 107.

- [Binary Outputs](#)

Use the button to open a view in which you can set the function of the binary outputs for the respective I/O communication module. There is more information in the section *Binary Outputs* on page 108.

- **Analog Inputs**


Use the button to open a view in which you can set the function of the analog inputs for the respective I/O communication module. There is more information in the section *Analog Inputs* on page 109.

- **Analog Outputs**

Use the button to open a view in which you can set the function of the analog outputs for the respective I/O communication module. There is more information in the section *Analog Outputs* on page 110.

8.2.2.1 Binary Inputs

The *Binary Inputs* button in the *Preferences* view of an added I/O communication module opens the *Binary Inputs* view.



Note that changes in this view are not saved and applied by the I/O communication module until you exit the view. Use the drop-down list to link the binary input of the I/O communication module displayed in the *Ch.* (Channel) column to the following functions:

- **Not Used**

The binary input is not linked to any function.


- **Normal Operation Release for NO_{x1} / NO_{x2}**

A master control can signal to the respective NO_x monitor of the EasyNO_x via a closed binary input that the conditions for normal operation are met by the engine. In NO_x monitoring mode *Start/Stop via CANopen*, the binary input must be linked to this function.

8 Devices

8.2.2.2 Binary Outputs

The *Binary Outputs* button in the *Preferences* view of an added I/O communication module opens the *Binary Outputs* view.



Note that changes in this view are not saved and applied by the I/O communication module until you exit the view. Use the drop-down list to link the binary outputs of the I/O communication module displayed in the *Ch.* (Channel) column to the following functions:


- **Not Used**
The binary output is not linked to any function.
- **Error Output, Warning Output**
The binary output of the respective I/O communication module is assigned to the binary output *Error* or *Warning* of the EasyNO_x. If the binary outputs of the EasyNO_x are activated (see *Devices* on page 69), the EasyNO_x switches the assigned binary output of the I/O communication module if an accordingly configured monitoring function of the EasyNO_x requires it.
- **Cat. Temperature Error NO_x1 / NO_x2**
If the respective NO_x monitor of the EasyNO_x has detected a temperature error on the respective engine at least one of the configured exhaust gas temperature measuring points near the catalytic converter, the EasyNO_x switches the assigned binary output of the I/O communication module.
- **NO_x Exceedance NO_x1 / NO_x2**
If the provisional daily average of the nitrogen oxide concentration currently exceeds the configured level limit for the engine monitored by the respective NO_x monitor, the EasyNO_x switches the assigned binary output of the I/O communication module.

- **Normal Operation NO_{x1} / NO_{x2}**

If normal operation was detected by or signalled to the respective NO_x monitor of the EasyNO_x for the respective engine, the EasyNO_x switches the assigned binary output of the I/O communication module.

8.2.2.3 Analog Inputs

The *Analog Inputs* button in the *Preferences* view of an added I/O communication module opens the *Analog Inputs* view.



Note that changes in this view are not saved and applied by the I/O communication module until you exit the view. Use the drop-down list to link the analog input of the I/O communication module displayed in the *Ch.* (Channel) column to the following functions:

- **Not Used**

The analog input is not linked to any function.


- **Load Input for NO_{x1} / NO_{x2}**

The analog input is used by the respective NO_x monitor as input for the load signal from the respective engine. In NO_x monitoring mode *Load via CANopen*, the analog input must be linked to this function.

8 Devices

8.2.2.4 Analog Outputs

The *Analog Outputs* button in the *Preferences* view of an added I/O communication module opens the *Analog Outputs* view.



Note that changes in this view are not saved and applied by the I/O communication module until you exit the view. Use the drop-down list to link the analog output of the I/O communication module displayed in the *Ch.* (Channel) column to the following functions:

- **Not Used**
The analog output input is not linked to any function.
- **Average NO_x from NO_x1 / NO_x2**
Output of the provisional daily average of nitrogen oxide measured values converted according to VDMA 6299:2019-09 determined by the respective NO_x monitor. Scaling: 4 mA correspond to 0 mg/Nm³, 20 mA correspond to 1,000 mg/Nm³.
- **Actual NO_x from NO_x1 / NO_x2**
Output of the nitrogen oxide measured value currently measured by the respective NO_x monitor converted to standard volume with a reference oxygen content of 5 % according to VDMA 6299:2019-09. Scaling: 4 mA correspond to 0 mg/Nm³, 20 mA correspond to 1,000 mg/Nm³.

8.3 Generic Device

You can add one device that is not directly supported by the EasyNO_x as a *Generic* device and monitor its communication status.



Generic device is not displayed in the Start Menu

The generic device appears in the *Device Setup* view in the list of added devices (display name *Generic*). The device is not displayed in the *Start Menu*.


Functions

- When a generic device is added in Device Setup, it will be started, providing this has not already been done.
- The communication status is monitored by the EasyNO_x and is visualized in the menu bar (see section *Menu Bar* on page 64).
- Changes to the communication status are listed in the *Event Log* view (see section *Event Log* on page 86).

9 Errors

9.1 Possible Faults

Fault	Possible cause	Solution
 <p>The connection status symbol in the menu bar is yellow.</p>	<p>To at least one device there is no connection.</p> <p>The node ID of at least one added device is incorrect.</p>	<p>Establish the connection to the relevant devices.</p> <p>Set the correct node-ID for the relevant device.</p>
 <p>The connection status symbol in the menu bar is red.</p>	<p>No other device is connected.</p>	<p>Check the CAN bus wiring.</p>
<p>The display does not register touches at the desired position.</p>	<p>The display is dirty.</p>	<p>Clean the display (see section <i>Cleaning the Touchscreen</i> on page 115).</p>
<p>The displays on the screen are difficult to recognize.</p>	<p>The lighting conditions are unfavorable.</p>	<p>Adjust the display to the lighting conditions using the <i>Day Mode/Night Mode</i> button in the <i>Start Menu</i>.</p>
<p>The system time is repeatedly incorrect.</p>	<p>The internal battery is dead.</p>	<p>Have the battery changed (see section <i>Battery Change</i> on page 115).</p>
<p>An added device is indicating erroneous operating data.</p>	<p>Node IDs in the CAN bus are incorrectly assigned.</p> <p>The device is incorrectly wired.</p>	<p>Check the set node IDs of all devices connected to the CAN bus.</p> <p>Check the wiring of the device.</p>
<p>Data is not getting updated.</p>	<p>The wiring of the CAN bus is defective.</p> <p>The device is not sending any data (for example if it is defective or the software has crashed).</p>	<p>Check the CAN bus wiring and correct any defects found.</p> <p>Check the device and fix the problems.</p>
 <p>The symbol appears in the <i>Add Device</i> dialog next to devices.</p>	<p>This device has not been activated.</p>	<p>Activate the device with a software dongle (see section <i>Device Activation</i> on page 71).</p>

Fault	Possible cause	Solution
 <p>The device cannot be added, although the above symbol appears next to the device in the <i>Add Device</i> dialog.</p>	<p>The number of available activations for this device has been exceeded.</p>	<p>Activate the additional device with a software dongle (see section <i>Device Activation</i> on page 71).</p>
<p>When tapping on a device in the <i>Start Menu</i>, you get the error message "No connection to this device has been established!"</p>	<p>The wiring of the CAN bus is defective.</p> <p>The bit rate of the device does not correspond to the bit rate of the EasyNO_x.</p> <p>The node ID of at least one added device is incorrect.</p>	<p>Check the CAN bus wiring and correct any defects found.</p> <p>Set the correct bit rate for the device.</p> <p>Set the correct node-ID for the relevant device.</p>

9.2 Customer Service Information

You can reach our customer service during business hours at the following phone and fax number, or by email:

Phone: +49 5141 93 99 0

Fax: +49 5141 93 99 99

Email: service@motortech.de

9 Errors

9.3 Returning Equipment for Repair / Inspection

To return the device for repair and inspection, obtain a return form from your MOTORTECH contact person (see *Customer Service Information* on page 113).

After you have completely filled out the return form and returned it to MOTORTECH, MOTORTECH will send you back the return form and a delivery note with RMA number specified. Enclose the return form with your device and attach the delivery note to the packaging so that it is clearly visible from the outside. This guarantees a fast and smooth processing of your repair order.

Send the device with delivery note and return form to one of the two addresses below or to the nearest MOTORTECH representative:

MOTORTECH GmbH

Hogrevestr. 21–23
29223 Celle

Germany

Phone: +49 5141 93 99 0

Fax: +49 5141 93 99 98

www.motortech.de
motortech@motortech.de

MOTORTECH Americas, LLC

1400 Dealers Avenue, Suite A
New Orleans, LA 70123

USA

Phone: +1 504 355 4212

Fax: +1 504 355 4217

www.motortechamericas.com
info@motortechamericas.com

9.4 Instructions for Packaging the Equipment

For return shipment, equipment should be packaged as follows:

- Use packaging material that does not damage the equipment surfaces.
- Wrap the equipment with sturdy materials and stabilize it inside the packaging.
- Use sturdy adhesive film to seal the packaging.

10.1 Cleaning the Touchscreen

Clean the touchscreen of the EasyNO_x with a soft cotton cloth and alcohol.



Risk of destruction!

Dirt affects the function of the touchscreen. Water, fingerprints and other dirt should be removed immediately from the touchscreen and frame to avoid spots.



Risk of destruction!

Organic solvents as well as acids and alkaline solutions could damage the touchscreen. Therefore only clean the device with a soft cotton cloth and alcohol.

10.2 Maintenance of Housing

Service the housing of the EasyNO_x at least once a year. Carry out the following work:

- Check the hinges and the cam locks of the housing door for ease of movement. Spray the hinges of the housing door with a suitable, water-free lubricant.
- Check the seal in the contact edge area for damage. If the seal in the contact edge area is damaged, contact your MOTORTECH contact person (see *Customer Service Information* on page 113).
- Check all components and surfaces for external damage. To prevent seals from being damaged by temperature-induced freezing, you can treat them with common agents such as talcum, Vaseline, or wax.
- Check the housing for traces of corrosion. Repair damage to the housing as follows:
 - Damage to small areas affecting only a part of the surface (e.g. scratches): Lightly sand off the surface at the damaged place and remove all traces of corrosion and contamination. Depending on the degree of damage, apply 2K-PUR acrylic paint with a paint stick, a brush, or a spray can.
 - Large area damage: Smooth the surface uniformly and clean it with white spirit. Then paint over the entire surface with 2K-PUR acrylic paint.

10.3 Battery Change

The internal board of the EasyNO_x has a backup battery of the type CR1220, whose service life is approximately eight years, depending on use. To have the battery changed, contact your MOTORTECH contact person (see *Customer Service Information* on page 113).

10 Maintenance

10.4 Replacing the NO_x Sensor

At an average temperature of its evaluation unit of 90 °C (194 °F), the NO_x sensor of the CAN bus/NO_x sensor module has a service life of 6,000 hours. After this time the NO_x sensor must be replaced. You obtain a replacement sensor from MOTORTECH.

Proceed as follows to replace the NO_x sensor:



Operational safety!

To safely dismount the NO_x sensor, be sure to observe the following:

- To protect the NO_x sensor and yourself, wear ESD-compliant work gloves. To protect the NO_x sensor against electrostatic discharge, also comply with IEC 61340-5-1 and IEC TR 61340-5-2 in their respective valid versions.
- Under no circumstances touch the probe of the sensing element while dismantling.
- The NO_x sensor must not be live during dismantling and must have cooled down for at least 15 minutes after its last operation. Otherwise, touching the sensing element may cause burns, the sensing element may burn, and serious damage to the connected equipment due to arcing, sparking or short circuit may occur.
- If mechanical shock to the sensing element occurs (e.g. drop on the floor), the NO_x sensor must not be used under any circumstances and must be replaced. For this purpose, contact your MOTORTECH contact person (see *Customer Service Information* on page 113).
- The sensing element may be mounted and dismantled a maximum of two times. The electrical connection to the NO_x sensor's evaluation unit may be established and disconnected a maximum of 20 times. After that, proper functioning of the sensor can no longer be guaranteed.


1. First ensure the following:
 - The engine must be switched off during replacement.
 - The exhaust pipe must have cooled down sufficiently and there must be no exhaust gases in the exhaust pipe.
 - The EasyNO_x system must not be live.
2. Then disconnect the connection cable to the CAN bus module from the connector of the NO_x sensor's evaluation unit.
3. Dismount the evaluation unit from the mounting plate of the CAN bus/NO_x sensor module by loosening the two M8x20 hexagon screws.



Risk of destruction!

To avoid destroying the NO_x sensor, do not hit with a hammer when dismounting. In case the thread of the sensing element is stuck, use only oils without silicon or magnesium for loosening.

4. Make sure that the sensing element has not been in operation for at least 15 minutes. Then unscrew the sensing element from the welding boss using a 22 mm (0.87") wrench. The outgoing wires must not twist by more than 180°. Therefore counter the sensing element with your hand.
5. Remove the NO_x sensor.
6. At the mounting position of the sensing element, check the NO₂/NO_x ratio (correction factor K) in the exhaust gas with a suitable calibrated exhaust gas analyzer. More information on this is available in the section *Determining NO₂/NO_x Ratio* on page 45.
7. Remove the protective cap from the probe of the new NO_x sensor's sensing element. Do not pull on the connection cable, but hold the sensing element only by its metal body.
8. Check whether the thread of the sensing element is sufficiently greased. If necessary, re-grease it with high temperature grease. Also make sure that no dirt or dust gets deposited in or on the probe during replacement.
9. Insert the sensing element into the welding boss and screw the sensing element into the welding boss via its hexagon nut by hand first. The outgoing wires must not twist by more than 180°. Therefore counter the sensing element with your hand.
10. Then tighten the sensing element over its hexagon nut using a calibrated torque tool with a torque of 50 Nm ± 10 Nm (36.9 lb-ft ± 7.4 lb-ft). Make sure that the minimum bending radius of the connection cable of 20 mm (0.79") is observed and that the angle of the cable outlet at the sensing element grommet is less than 15°.



11. Then mount the evaluation unit of the NO_x sensor onto the mounting plate of the CAN bus/NO_x sensor module using the two hexagon screws M8x20 and a tightening torque of 10 Nm (7.4 lb-ft).
12. Make sure that there are no particles in the five-pin connector of the NO_x sensor's evaluation unit and that the five-pin connector is dry.

10 Maintenance

13. Connect the connection cable to the CAN bus module to the five-pin connector of the evaluation unit.
 - ▶ The NO_x sensor has been replaced.
14. After you have put the EasyNO_x system back into operation, correct the NO₂/NO_x ratio determined above in the *NO_x Thresholds Settings* view (see section *Preferences* on page 101) for the respective NO_x monitor, if necessary.
 - ▶ You can put the NO_x monitoring of the EasyNO_x back into operation.

10.5 Software Update



Risk of software damage!

The power supply must not be interrupted under any circumstances during the software update. Otherwise, this can lead to serious errors and the EasyNO_x will no longer work.



Backup software dongles and configuration


Before updating the software, backup the software dongles of the activated devices (see section *Devices* on page 69) and the EasyNO_x configuration (see section *Display* on page 76).

You receive software updates for the EasyNO_x from MOTORTECH. A software update consists of several update files with signature files for verification of the update files. You need a USB flash drive to install updates. The current software version of your EasyNO_x is displayed in the *Display Information* view (see section *Display* on page 76).

Perform updates as follows:

1. Read and observe all information provided with the update (e.g. README file).
2. Make sure that the update files correspond to the board support package of your EasyNO_x. The *Display Information* view (see section *Display* on page 76) displays the installed board support package of your EasyNO_x. In the file name of the update files you can identify the board support package by the version number after *BSP* (e.g. *rocko-7.0-0*).
3. Save the update files with the extension *.tar.bz2* and the corresponding signature files with the extension *.sha1* in the root directory of a USB flash drive.

4. Insert the USB flash drive into your running EasyNO_x.
 - ▶ After a few seconds, the standard EasyNO_x interface closes and the installer interface opens.



5. Available update packages are displayed in the *Package* column. If necessary, tap on the *Language* button to change the language. Under *Installed* the version of the respective package installed on the EasyNO_x is displayed, under *New* the version to which the respective package in the EasyNO_x will be updated. As a rule, the suitable update packages are preselected. To change the selection if needed, activate or deactivate the checkbox under *Select* for the respective packages. To install the selected packages, tap *Install*.
 - ▶ The selected update packages are installed. After an installer update, the installation of the remaining packages must be restarted by tapping the *Install* button.
 - ▶ Certain update packages may require a restart of the EasyNO_x.
6. After installing the desired update packages, exit the installer by tapping the *Quit* button and remove the USB flash drive.
 - ▶ You can now use the EasyNO_x with the new software.

MOTORTECH GmbH

Hogrevestr. 21–23
29223 Celle
Germany

Phone: +49 (5141) 93 99 0
Fax: +49 (5141) 93 99 99
E-Mail: sales@motortech.de
Web: www.motortech.de

MOTORTECH Americas, LLC

1400 Dealers Avenue, Suite A
New Orleans, LA 70123
USA

Phone: +1 (504) 355 4212
Fax: +1 (504) 355 4217
E-Mail: info@motortechamericas.com
Web: www.motortechamericas.com

MOTORTECH Shanghai Co. Ltd.

Room 1018 Enterprise Square,
No. 228 Meiyuan Road,
Jing'An District, 200070 Shanghai
China

Phone: +86 (21) 6380 7338
E-Mail: info@motortechshanghai.com
Web: www.motortechshanghai.com

GAS ENGINE TECHNOLOGY

Ignition Systems	
Spark Plugs & Accessories	
Gas Engine Control Systems	
Sensor Systems	
Air/Fuel Ration Control Systems	
Exhaust Gas Aftertreatment	
Gas Engine Accessories	